

User Profiles

User profiles help the chair remember what you like. Your profile saves your preferred settings and your most recent health scan, which appears on the Home screen.



Active User: Your currently selected User profile appears on the Home screen, so you can quickly confirm whose saved settings are in use.




Adding a User: From the Home screen, tap the + button. Select a new User number for your profile, and remember it for future sessions. To use the chair without saving any settings, select Guest instead.



Change Users: Tap this button if someone else was the last person to use the chair. Select your User number to access your saved settings and data. From this screen, you can also delete a User number to make it available for a new user.


Health Scan

Use this screen to begin a Health Massage session. The chair analyzes your health metrics and recommends a personalized message program based on your results.



Health Scan Sensor

- Step 1:**
If the chair is not already powered on, press the Power button to turn it on. Place your right thumb on the Health Scan sensor located on the right Quick Access Panel.
- Step 2:**
While keeping your thumb on the sensor, tap the Health button on the tablet screen.
- Step 3:**
Remain still while the chair measures your heart rate, blood oxygen level, and fatigue status.
- Step 4:**
Once the scan is complete, review your results and select "Run Intelligent Massage" or Start a Re-Scan.



Share a photo and tag us:

X @infinity_chairs

Instagram @Infinitymassagechairs

f @Infinitymassagechairs

Don't forget to use
#infinitymassagechairs

INFINITY®

72 Stard Road, Seabrook, NH 03874 | 603-910-5000
www.infinitymassagechairs.com

Version 1.0

INFINITY®


MESSAGE CHAIRS

Quick Start Guide

Circadian® 4D DualFlex SE Massage Chair




Alternatively, scan the
QR code to watch a
remote tutorial video.



Auto Programs – Select from 12 pre-set auto programs. To select simply tap the Auto icon on the bottom screen.



Manual Mode – Use this screen to fully customize your own massage and find the perfect treatment for you.




Memory Slots – Have a favorite auto or manual massage session? Just save it to memory for easy recall later.

INFINITY®


Power Button & Device Volume – Located at the top left of the tablet. Use the Power button to turn the tablet on or off. Use the adjacent volume control to increase or decrease audio volume.



Home Screen – After turning on your chair, this is the first screen you will see on your tablet. Use this screen to navigate all menu options.




Health – Place your right thumb on the health scanning sensor on the quick access panel. The chair will scan your finger and produce a health report eventually offering you a massage program tailored to your results.



SootheMe® Sounds – Enjoy 12 calming nature sounds designed to complement your spa-like atmosphere.



Adjustment – While your massage program is running in auto or manual, take over and customize your settings.



System – Customize chair settings including Bluetooth®, voice guidance, volume levels, and more.