




QUICK START GUIDE

RECOMMENDED PSI




iLAND™ Chair, Bar & Mini Bar, Hammocks
6 PSI (0.41 BAR) – 8 PSI (0.55 BAR)


INFLATING AND DEFLATING



AIR VALVE CAP



CLOSED / UP POSITION



OPEN / DOWN POSITION

INFLATION



HAND PUMP

- 1 Attach the hose to the air pump.
- 2 Locate the air valves on the iLAND (see above images) and open the air valve cap.
- 3 Before connecting the hose to the iLAND, make sure the air valve is in the CLOSED/UP position.
- 4 Connect the hose to the iLAND by pressing down and twisting clockwise. Once connected, set the pump to SETTING 1 and begin inflating.
- 5 Midway through inflation, when operating the air pump becomes more difficult, set the pump to SETTING 2, then continue inflating.
- 6 Once the board is fully inflated, disconnect the hose from the air valve by twisting it counter-clockwise. It is normal to hear a small amount of air escape when removing the hose.



12V E-PUMP

- 1 Before connecting the hose, make sure the inflation valve is in the CLOSED/UP position.
- 2 Connect your hose to the inflation port and lock it in place. Then insert opposite end of the hose into the valve on the inflatable and lock into position.
- 3 Long press the power button to turn on the pump. The factory set target pressure is 12 PSI.
- 4 Adjust the pressure by pressing the [+ button] or [- button] to preset the target pressure. (0.5~20 PSI)
- 5 Press power button again to start inflation.
- 6 Once you hit the ideal PSI, disconnect the hose, and turn off the pump.

iROCKER



QUICK START GUIDE

DEFLATION

12V E-PUMP

- 1 Attach the hose to the DEFLATE nozzle on the E-pump.
- 2 Locate the air valve on the iLAND and open the air valve cap.
- 3 Press firmly on the pressure release pin for 2 seconds, then twist clockwise to lock into the OPEN/DOWN position. Press and close valve.
- 4 Connect the hose to the valve.
- 5 Press Power Button and let the deflation process continue until the iLAND™ is completely deflated and flat.
- 6 Press Power Button again to stop the deflation process when the iLAND™ is fully deflated.
- 7 Disconnect the hose.

HAND PUMP

- 1 Make sure the air valve is DRY.
- 2 Press firmly on the pressure release pin for 2 seconds, then twist to lock into the OPEN/DOWN position.
 Be prepared for a loud rush of air when opening the air valve.
- 3 Allow air to escape from the iLAND™ for a few minutes before folding.
- 4 Connect Hand Pump hose to the DEFLATE nozzle of the pump.
- 5 Connect other end of the hose to the valve by pressing down and twisting clockwise.
- 6 Use Hand Pump to suck out all air from inside of the iLAND™.
- 7 Disconnect hose from the valve and close.

MAGTITE ACCESSORY MOUNT

Elevate your adventure with MAGTITE—our innovative magnetic mounting system designed for ultimate convenience! Seamlessly integrated into the deck of our SUPs and iLAND™ products, MAGTITE mounts let you secure your gear in seconds. Need more flexibility? Our add-on MAGTITE pucks give you the freedom to attach compatible accessories wherever you go. No screws, no hassle!



Integrated MAGTITE Puck compatible with all MAGTITE accessories



iRocker Drinkware is a great complement to any iLAND™ product.



NOTE: For more information on the MAGTITE magnetic mounting system, to <https://irockersup.com/pages/product-manuals-catalogs>.

Tips on how to properly store your iLAND™ products.

Rinse & Clean: After each use—especially in salt water—rinse your iLAND™, including the PVC, handles, and deck. Use soap if needed, then rinse thoroughly.

Dry Completely: Ensure the iLAND™ is fully dry before storing, paying extra attention to deck padding and woven fibers to prevent mold or glue damage.

Roll & Store: Store in a temperature-controlled environment after drying. Avoid extreme heat and humidity to protect the PVC glue.

Deflate Slightly: Reduce PSI by 1-2 when not in use to prevent overinflation from heat and sunlight, which can weaken seams.

Glue Repairs: Use PVC glue for minor glue issues (under ½ inch). For larger problems, contact our Customer Experience team for assistance.

iROCKER



Have questions? We're here to help.

1-866-985-8367

irockersup.com