


The friendly user guide for





The Chair



What's included...


The Chair

- A. Seat + harness
- B. Belly bar
- C. Tray
- D. Cross bar + foot rest
- E. Allen key
- F. High chair legs (x4)
- G. Bolts (x4)
- H. Washers (x4)



Step 1

Click in all four legs to the base of the seat.




Step 2

Line up the cross bar with the holes on the legs. Place one washer on each bolt. Insert bolts and tighten with a quarter turn on each bolt until they are all secured. Then add a further quarter to half turn per bolt as allowed. Do not over tighten but ensure they're tight.

PRO TIP

When your child grows the foot rest can be reversed for better leg support.



Step 3

Put belly bar bottom tab through the front slot on the seat. Then take the right and left tab one at a time and push it through the side square holes in the seat. Push through the hole until you hear a loud click.




Step 4

To slide on the tray, line up the grooves with the lip of the belly bar. You may need to push on the center until you hear it click.




More than a high chair.



When your little one gets bigger, extend the life of your chair by swapping in the booster base or little legs to create The Booster or The Play Chair.



High Chair + Booster Conversion Kit
= **The Booster**




High Chair + Play Legs
= **The Play Chair**



Scan to purchase accessories.

Using the Harness

To ensure your child is safely seated in The Chair, grab the center button which is attached to the crotch strap, and insert both straps into the center button until you hear a click. Adjust strap tightness until your child is secure.



To unlock the harness, press the center 'Lalo' button.


Extra Comfort!

Please note: The cushion is sold separately and is not included with your high chair purchase. If you've opted for the add-on cushion, here's how to easily attach it.



Taking your washable cushion on and off your chair is easy. To put on, simply pull harness straps through the back of the cushion before stretching around the chair frame and snapping at the back.


Wrap the cushion around the top and sides of the chair. Snap the back and then sides.



Scan to purchase The Cushion.

Complete your mealtime setup.

Everything you need for a solid start to solids. Our tableware is dishwasher safe and made with FDA approved non-toxic and BPA free silicone.



Bib



Little Spoon



Little Cup



Suction Bowl



Suction Plate



Scan to purchase tableware.

Safety First

Important! Read carefully and keep for future reference.

⚠ WARNING

- **FALL HAZARD:** Children have suffered severe head injuries including skull fractures when falling from high chairs. Falls can happen suddenly if child is not restrained properly
 - **ALWAYS** use the restraints, and adjust to fit snugly
 - Tray is not intended to hold child in chair
- **NEVER** leave the child unattended. Stay near and watch child during use
- Prevent burns: Keep high chair away from open fires and sources of strong heat
- Prevent tip over and falls: Do not allow child to push feet against table or other structure
- Do not use the high chair until your child can sit up unaided
- Do not use the product if any part is broken, torn or missing or if any fasteners are loose. Check all fasteners regularly and tighten as needed
- This product is only suitable for indoor use
- **NEVER** use with accessories or replacement parts not approved by Lalo for use with this product
- Stay near and watch your child during use
- Carefully wash all parts that come in to contact with food before using the high chair
- Adult assembly required: package contains small parts, some of which may have sharp edges

Cleaning & Care


- **Maximum Child Weight (High Chair):** 33 lbs
- **Product Weight:** 10 lbs
- Tray is top rack dishwasher safe
- Wipe all surfaces clean with water and mild dish soap. For larger cleanups, straps can be removed and are top-rack dishwasher safe. Let air dry and avoid using bleach.
- If any part is broken or missing please email: lalofam@meetlalo.com or call **646-863-5225**

Sold separately:
The Cushion

- Cotton cushion is machine washable with cold water. Air dry only. Wash separately. Do not dry clean, do not tumble dry, and do not use bleach.
- Vegan leather cushion should be wiped down with water and mild soap. Do not machine wash.

Save us a seat at the table!

Tag @lalo to share your family meals.



Need assistance? Scan to watch quick setup videos.