

LIFETIME

KAYAK OWNER'S MANUAL

Transportation

Use caution when transporting your kayak. Be sure to tie down your kayak, but do not overtighten the straps.

Storage

- Be sure to empty the kayak of all water.
- You should clean the kayak by rinsing with freshwater, especially if the kayak has been used in salt water or becomes muddy.
- Store the kayak out of direct sunlight.

Usage

Sit in the cockpit area of the kayak, centered in the provided seat area. Using the foot braces, secure your feet so your knees are bent and feel sturdy. Paddle with your arms evenly apart at a medium speed switching back and forth from one side to the other. The paddle should enter the water around your shins and pull out of the water around your hips.



WARNING



Paddle sports can be physically demanding and dangerous.

- ANYONE using this watercraft may be at risk of serious injury or death.
- ALWAYS wear a Coast Guard-approved, PERSONAL FLOTATION VEST.
- OBTAIN certified watercraft and first-aid training, and carry first aid and safety/rescue equipment.
- CONSULT a physician PRIOR to beginning your paddle sport training.
- This watercraft is intended for RECREATIONAL USE ONLY.
- This watercraft is NOT intended for mechanical propulsion.
- Scout unfamiliar waters; portage where appropriate.
- NEVER use this watercraft in rough, stormy or whitewater conditions.
- This watercraft is NOT intended to be used as a lifesaving device.
- DO NOT allow minors to use this watercraft without adult supervision.
- DO NOT use in areas where dangerous or strong current flows can overcome your ability to control your direction or destination.
- NEVER use drugs or alcohol BEFORE or DURING operation of this watercraft.
- ALWAYS paddle with a buddy in case you require emergency help.
- NEVER use in cold water that may cause hypothermia.
- ALWAYS wear a helmet when appropriate.
- CHECK your equipment PRIOR to each use for signs of wear or failure.

1169432 C

Keep this Identification Number in case you must contact our Customer Service Department.



CLEANING & CARE

Congratulations on your Lifetime® product purchase. By following the instructions below, your new Lifetime® product should provide you with years of service and enjoyment.

Cleaning and Care

Lifetime® watercrafts are stain- and solvent-resistant. Most stains can be removed, using a mild soap and a soft-bristled brush. Abrasive cleaning materials may scratch the plastic and are not recommended. Avoid placing a direct heat source on or near surfaces unless using a heat barrier.

Helpful Tips For Your Kayak and Paddleboards

Always store your watercraft out of direct sunlight when not in use. Your watercraft is manufactured with UV-resistant color, but a watercraft stored in direct sunlight over long periods of time will color fade.

- Your new watercraft is molded of high-density, polyethylene resin. Periodic cleaning with mild soap and water is recommended to keep your kayak looking new.
- Never drag any portion of the watercraft over asphalt, rocky, sandy or abrasive surfaces.
- Do not stand or sit on your watercraft when out of the water. This can damage the watercraft.
- During regular use, it is normal to find small amounts of water inside or on the watercraft. Carefully unscrew the drain plug and tilt the watercraft to let the water drain out. Secure the drain plug when finished.
- If your watercraft has been exposed to hot sunlight, it is recommended to splash water on the hull to cool the hot surface before it comes in direct contact with your skin. This should also be done for any paddles you may have.

****U.S. and Canada customers ONLY****

IF ASSISTANCE IS NEEDED,

DO NOT CONTACT THE STORE!

CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865

****For customers outside the U.S. or Canada, please contact the store for assistance.****

Please have the Product ID ready when you call; it is located at the bottom of the first page of this instruction.