

little tikes®

485176M

XIM485176-1R2 - 11/19

www.littletikes.com
www.littletikes.co.uk
www.littletikes.nl
www.littletikes.pl

ENGLISH

BAKE 'N GROW™ KITCHEN

Ages: 1½ years & up
Please save sales receipt for proof of purchase.

WARNING: ADULT ASSEMBLY REQUIRED.

- Keep these instructions for future reference.
- Prior to assembly, this package contains small parts: hardware which is a choking hazard and may contain sharp edges and sharp points. Keep away from children until assembled.
- This product is intended for indoor/outdoor family use only.
- This product is intended for use by children ages 1½ years and up.
- Do not allow children to sit, stand, play or climb on the top surface. Failure to do so may cause the product to become unstable.
- Protect your eyes. Always wear safety glasses when using power tools.
- Thoroughly wash accessories before contact with food or beverage.

DISPOSAL

- Disassemble and dispose of equipment in such a manner that no hazardous conditions such as, but not limited to, small parts and sharp edges exist at the time equipment is discarded.

CONSUMER SERVICE

TOLL-FREE NUMBER:

United States:
www.littletikes.com
1-800-321-0183 Monday - Friday
The Little Tikes Company
2180 Barlow Road
Hudson, OH 44236
E-mail: service@littletikescare.com

United Kingdom:
www.littletikes.co.uk
Little Tikes, MGA Entertainment (UK) Ltd
50 Presley Way
Crownhill
Milton Keynes MK8 0ES
Bucks, UK
Tel: +0 800 521 558
E-mail: support@LittleTikesStore.co.uk

MGA


CE

Imported by MGA Entertainment Australia Pty Ltd
Suite 2.02, 32 Delhi Road
Macquarie Park NSW 2113

Printed in U.S.A. D.R. ©2019 The Little Tikes Company
© The Little Tikes Company, an MGA Entertainment company. LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes. Please keep this address and packaging for reference since it contains important information. Contents, including specifications and colors, may vary from photos depicted on package. Instructions included. Please remove all packaging including tags, ties & tacking stitches before giving this product to a child.


LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers.



Adult assembly required / Le montage devra être effectué par un adulte / Debe ser armado por un adulto

Tools required (not included)
Outils Requis (non compris)
Herramientas Requeridas (no incluidas)




(Recommended)
(Recommandé)
(Recomendado)

M x2
1.25" Screw / Vis de 3,17 cm / Tornillo de 3.17 cm

N x3
3" Screw / Vis de 6.35 cm / Tornillo de 6.35 cm

Parts / Pièces / Piezas



A. Kitchen wall / Paroi de la cuisine / Pared de la cocina



B. Countertop / Plan de travail / Encimeradelfregadero



K. Refrigerator base
Base réfrigérateur
Base del refrigerador

L. Oven base
Base four
Base del horno




Accessories / accessoires / accesorios



C. Oven hood / Hotte / Campana del horno



D. Base connector / Connecteur des bases / Conector de las bases




E. Faucet
Robinet
Grifo



G. Burner cover
Couvre-brûleur
Cubierta del quemador



H. Burner
Brûleur
Quemador



J. Knobs - white (6)
Boutons - blanc (6)
Perillas - blanco (6)

Step 1: Decals


Étape 1 : Autocollants

Paso 1: Calcomanías

Decals must be applied to a clean, dry surface. Wipe clean with a dry rag before application. Remove air from under decals by applying pressure to the decals starting from the center, and work towards edges. NOTE: If decals bubble, prick with a pin to remove the air.

Les autocollants doivent être appliqués sur une surface propre et sèche. Essuyez avec un chiffon sec avant l'application. Retirez l'air sous les autocollants en appliquant une pression sur ceux-ci, en partant du centre et en allant vers les bords. REMARQUE: en cas de bulles sous les autocollants, percez-les avec une aiguille pour éliminer l'air.


Las calcomanías deben aplicarse en una superficie limpia y seca. Limpie la superficie con un trapo seco antes de colocarlas. Quite el aire atrapado debajo de las calcomanías haciendo presión desde el centro hacia los bordes. NOTA: Si se forman burbujas en las calcomanías, pínchelas con un alfiler para quitarles el aire.



Step 2: Faucet and knobs

Étape 2 : Robinet et boutons

Paso 2: Grifo y perillas



Secure the faucet from underneath the countertop using the faucet fastener.

Fixer le robinet par le bas du comptoir au moyen de la pièce de fixation du robinet.



Fije el grifo con el sujetador desde abajo de la encimera.





Step 3: Burners / Étape 3 : Brûleurs / Paso 3: Quemadores




Burner cover / Couvre-brûleur / Quemador



Align the cover post to the hole in the burner recessed area on the countertop.
Aligner le taquet du couvre-brûleur sur le trou du brûleur situé dans la partie encastrée du comptoir.
Alinee la clavija de la cubierta con el orificio en el hueco del quemador ubicado en la encimera.




From the top, secure the burner using a 1.25" (3,17 cm) screw. Be sure screw is COMPLETELY tightened.
Fixer le brûleur par le haut au moyen d'une vis de 3,17 cm (1,25"). Serrer la vis À FOND.
Fije el quemador desde arriba con un tornillo de 3,17cm (1,25"). Asegúrese que el tornillo quede COMPLETAMENTE ajustado.




Place burner into recess. From underneath the countertop, secure using a 1.25" (3,17 cm) screw.
Poser le brûleur dans la partie encastrée. Le fixer par le bas du comptoir au moyen d'une vis de 3,17 cm (1,25").
Coloque el quemador en el hueco. Fijelo con un tornillo de 3,17cm (1,25") desde abajo de la encimera.


Step 5: Attach countertop to wall / Étape 5 : Fixation du comptoir à la paroi / Paso 5: Coloque la encimera en la pared



When pushing kitchen wall down into countertop - be sure rings are in a downward position.
En exerçant une pression vers le bas sur la paroi de la cuisine pour l'insérer dans le comptoir, vérifier que les tiges de blocage sont orientées vers le bas.
Cuando empuje la pared de la cocina en la encimera, asegúrese que las clavijas de retención estén hacia abajo.



Insert kitchen wall into countertop and push down. Secure using (2) 3" (6,35cm) screws.
Insérer la paroi de la cuisine dans le comptoir et exercer une pression vers le bas. Fixez à l'aide de vis (2) de 3 po (6,35 cm).
Inserte la pared de la cocina en la encimera y empújela hacia abajo. Fíjela con 2 tornillos de 6,35 (3").




N x2 - 3" (6.35 cm)

Step 4: Hood / Étape 4 : Hotte / Paso 4: Campana




Place the hood onto the front of the kitchen wall. Push upward.
Poser la hotte sur l'avant de la paroi de la cuisine. Exeracer une pression vers le haut.
Coloque la campana en el frente de la pared de la cocina. Empújela hacia arriba.



Hint: be sure hood is pushed up as far as it will go.
Astuce : vérifier que la hotte est poussée aussi haut que possible.
Consejo: Asegúrese de empujarla lo más arriba posible.

N x1 - 3" (6.35 cm)


Locate screw hole on the back of the kitchen wall, secure using a 3" (6,35cm) screw.
Repérer le trou de vis à l'arrière de la paroi de la cuisine, fixer la hotte au moyen d'une vis de 6,35 cm (3").
Ubique el orificio del tornillo en el lado posterior de la pared de la cocina y fijela con un tornillo de 6,35cm (3").



Stage 1 • Étape 1 • Etapa 1



Slide assembled countertop/kitchen wall into notched side of refrigerator base and oven base.
Glisser l'ensemble comptoir/paroi de la cuisine dans la partie rainurée de la base réfrigérateur et de la base four.
Deslice el conjunto de encimera/pared de cocina en las muescas a los lados de las bases del refrigerador y horno.



K **L**



Storage for connector. (Connector not needed for Stage 1.)
Compartiment de rangement du connecteur. (Le connecteur n'est pas nécessaire pour l'Étape 1)
Lugar para guardar el conector. (El conector no es necesario para la Etapa 1.)

