

OPERATING MANUAL

BIRD VERTICAL DISPLAY SYSTEMS



IMPORTANT SAFEGUARDS

WARNING

To guard against injury, basic safety precautions should be observed, including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

DANGER

To avoid possible electric shock, special care should be taken in the use of this equipment.

For each of the following situations, do not attempt repairs yourself;
contact an authorized service facility for service.

1. Do not operate appliance if it has a damaged cord or plug, or if it is malfunctioning or if it is dropped or damaged in any manner.
2. Close supervision is necessary when any appliance is used by or near children.
3. To avoid injury, do not contact moving parts or hot parts such as reflectors, lamp bulbs, etc.
4. Always turn off power at main disconnect when not in use, before putting on or taking off lamp bulbs. Never yank a cord to pull a plug. Grasp the plug and pull to disconnect.
5. Do not use an appliance for other than intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
6. Make sure appliance is installed properly before operating it.
7. Read and observe all the important notices on the appliance.
6. This appliance is to be installed with all appropriate codes and ordinances.

SAVE THESE INSTRUCTIONS

The Vertical Display System for Birds. Easier Maintenance, Increased Sales!



This manual will provide you with the information you need to successfully operate and maintain your Bird Vertical Display System. Please read it carefully and keep it for future reference.

**Congratulations on your new, “Plug and Play” Marineland Bird
Merchandiser purchase!**

**Improve your sales, enhance viewing and use less energy!
All part of the Marineland Bird Cage Merchandiser.**

Your fully integrated Marineland, 3-Tier Bird System provides easy-to-maintain enclosures with Slide-out removable cages for easier cleaning and better hygiene.

The birds will love it and you will appreciate all the extra features the Bird Display System has to offer.

FEATURES

- 1 ► REMOVABLE CAGES TO ACCESS LIGHT FIXTURES AND FOR EASIER CLEANING OF UNIT AND CAGES.
- 2 ► REMOVABLE SLIDE-OUT SUBSTRATE TRAYS AND GRATES
- 3 ► PERCHES AND FEEDING/WATER BOWLS FOR EACH CAGE
- 4 ► FLUORESCENT LIGHTING
- 5 ► OPTIONAL MANUAL LOCKS FOR EACH CAGE
- 6 ► ALUMINUM CLADDING AND DURABLE ABS PANELS

1



2



5



6



SYSTEM SPECIFICATIONS – 3 TIER BIRD CAGE DISPLAY SYSTEM

MECHANICAL (approximate):

Size: 42^{1/4}"L x 21^{3/4}"W x 80"H

Locking System: Manual Locks (Optional)

ELECTRICAL:

Voltage: 120 VAC / 60Hz, 1 AMP

LIGHTING:

Lights: 3-each T8-25 watt Fluorescent

BUYER SUPPLIED CONNECTIONS:

Cord Connection: 120 VAC, 60 Hz, 15 AMP (plug and play)



INSTALLATION INSTRUCTIONS

Step 1: Position Bird Display System

With the assistance of at least one other person, move the pallet/crate with Bird Display unit to the installation area.

NOTE: To ensure easier installation, do not remove the Bird Display unit from the pallet/crate, until you have moved the unit to the installation area.

Use a pallet jack if possible.

Step 2: Unwrap/Remove Bird Display


With assistance, unwrap and remove unit from pallet/crate.

Step 3: Level Assembled Rack

Place the unit where you want it to be and check horizontal and vertical levels. Adjust Leveling Legs as necessary.

Step 4: Plug in Bird Display System

Have the Lighting System connections plugged into the appropriate receptacle.



For system technical support call the MaRS Technical Support Division: (800) 576-6277

MAINTENANCE

Enclosure Maintenance (as needed)

After removing substrate , bowls and other décor within the enclosure, use a damp cloth to remove dirt , dust and bird waste (a mild soap can be used if necessary).

*A damp cloth can also be used to remove dirt , dust and bird waste from within the within the trays and on the grates within the unit.

*Use a mild soap if necessary, do not use abrasive pads or harsh chemicals to clean the cages or modular. **DO NOT USE DAMP CLOTH ON ELECTRICAL COMPONENTS (lighting).**

*For a more thorough cleaning, the cages can be removed away from the Bird Unit.

Safety note: if possible, it's recommended that assistance is used to remove the cages from the Bird Display. Carefully remove the cages to prevent cosmetic damage to the bird unit.



FLUORESCENT LAMP REPLACEMENT

To ensure maximum illumination and color reflection, we recommend that you replace with the same lamp type for proper operation. To replace them with “Cool White” or other lamps of lesser quality will greatly lessen lighting intensity and overall effect. The fluorescent lamp provides a pure white Full Spectrum illumination.

1. To replace the fluorescent lamp, simply unplug the light power.
NEVER change lamps on fixture while it's on.
2. Remove the cage(s) within, (this procedure makes it easier to replace lamps).
3. Remove fluorescent lamp. Gently twist 90 degrees and push backward and out from mounted station slots. Discard (according to established environmental procedure).
4. Replace discarded lamps with new lamps. Gently insert ends into slots and push up and forward or up and back until lamp fits securely in place.
5. After replacing the lamp, plug in the Bird System light power cord. Make sure the new lamp works before replacing the cage.

To order Fluorescent lamps, please call Marineland at 800-576-6277.

MANUAL LOCK INSTRUCTIONS

Operating Instructions.

This lock is preset at the factory to open at 0-0-0.

To set own combination:

1. With dials at 0-0-0, pull out shackle.
2. Turn shackle counterclockwise 90° (1/4 turn) and press it down.
3. Continue pressing shackle and turn another 90° (1/4 turn).
4. Set the dials to your own combination.
5. Turn shackle clockwise back to the original 90° position. Lift and return shackle to closed position.



Cage Locking Instruction..

1. Loop small cable through Cage door and through bottom grate handle.
2. Once looped connect cable to lock and press close.





LIMITED WARRANTY

Marineland warrants their Bird Display systems for one year against defects in materials or workmanship. This warranty applies only to the system and does not cover water quality, live product, replacement parts or maintenance supplies.

If your system is found to be defective - and has not been modified, damaged or misused – call Marineland Commercial Aquariums (toll free) at (800) 576-6277 or fax us at (805) 517-7198. All calls received during regular business hours (8am - 5pm, Pacific Time) will be responded to within 24 hours. Please have your manual and the system serial number ready.

In most cases, the problem will be resolved by a simple maintenance procedure, recommendation or repair authorization. Upon authorization, and in instances where outside repair or replacement of parts is necessary, Marineland will absorb all appropriate costs.

Damage or injuries resulting from negligence, misuse or user modification are not covered by this warranty. Incidental or consequential damages are specifically excluded.

** This warranty gives you specific legal rights. You may also have other rights which vary from state to state.*

** Because some states do not allow the exclusion of incidental or consequential damages, this exclusion may not apply to you.*

CUSTOMER SERVICE

For emergency problems with this system, call the
MaRS Customer Service, Technical Support
at 800-576-6277

For non-emergency problems or questions please call the above
number from 7a.m. – 5p.m. Monday – Friday.

CONSUMABLES ITEMS

SERVICING ITEMS

ADDITIONAL ITEMS

Z0----- 8/12



All Fluorescent Lamps and Ultra Violet
Lamps contain mercury.

Dispose of Properly.



A Division of The United Pet Group · Moorpark, CA 93021