





M6S Remote



M6S Remote INSTRUCTION

Ambient light mode



On/Off




Double-click  Turn on or off ambient light mode



In this mode, the brakes will flash

Only VOYAGER X Limited can be used


M6S Remote Adjustable Parameters



THUMBWHEEL:OK CHARGING...
DRIVE MODE : 2WD-LOCKED
UNIT : MPH
DRIVE TRAIN : PULLEYED
WHEEL DIAMETER : 175
MOTOR POLE PAIRS : 7
SPEED RATIO : 1:4.4
BRIGHNESS : 100%


- Turn off the remote and long press "Function" with "power" to remote menu.
- Use "Scroll wheel" to choose parameter, Use "Function" and "Power button" to turn page.
- Long press "Power button" to save the setting.

To Pair With Your Board




NO.1

Press "power button" to turn on your board, and then keep pressing for 7s until it is blinking.



NO.2

Press "power button" 3s to turn on your remote



NO.3

Hold the "FUNCTION" and "POWER" button of remote at the same time quickly (keep trying a few times if fail in the first time)