


Safety Information

- 1. Do NOT operate this product with wet hand.
- 2. Do NOT touch the atomization piece, or it could be damaged.
- 3. Do NOT switch on the sprayer when the water tank is empty.
- 4. Do NOT move the product when it is working.
- 5. Do NOT tilt the product or put it on unstable surface to prevent water leakage.
- 6. Do NOT use hot water over 40 °C or 104°F
- 7. Do NOT tear down the product on your own.
- 8. Do keep the power adapter and the product base dry before power on the product.
- 9. Do place the product away from child, pet, and electronic home appliances.
- 10. Do clean the water tank every 3~5 days to keep the product clean.


Package Contents



1 x Smart Wi-Fi
Essential Oil Diffuser



1 x Measuring Cup




1 x Power Adapter




1 x User Manual

LED and Button Rules



- A — LIGHT Button
Short press to turn on ambient light and cycle the color.
Long press 5s to turn off the ambient light.
- B — MIST Button
Short press to switch among off mode, light spray mode, and heavy spray mode.
Long press 5s to reset the product.
- C — Status LED
Flashing green(once/sec): Ready for pairing.
Flashing green(twice/sec): Pairing or resetting.
Solid green: Wi-Fi connected and working normally.



Installation Guide

- Hardware Installation

- 1. Detach the upper cover.
- 2. Plug in the power cable and place the product onto a stable surface.
- 3. Use the measuring cup to add water and then add 2~3 drops of essential oil for each 100ml water. Do NOT add when the power is on. Do NOT excess the MAX mark in the water tank.
- 4. Attach the cover and plug the power adapter in a socket. You will hear the product “Beep” once.
- 5. Short press the LIGHT button to turn on the ambient LED light. The color will start to cycle automatically. If you prefer a certain color, you can short press the LIGHT button again to keep the current color. Short press the LIGHT button again and then color will start to cycle automatically again. Long press the LIGHT button will turn off the ambient LED light.



Fig1




Fig2




Fig3




Fig4




Fig5



Fig6


- 6. Short press the MIST button to turn on the sprayer. Each time you short press the button, the product will cycle among light spray mode, heavy spray mode, and off. Long press the button will reset the product.

Attention:


- 1. If the product is knocked over by accident or water leaked accidentally, please unplug the power adapter immediately and then dry the product.
- 2. The amount and density of the spray vary slightly on different devices. It depends on water you use, temperature and humidity of the environment, and air flow in your room. It's not a product defect.
- 3. The product will power off automatically when water runs out.
- 4. Please use natural essential oil only. Any chemical ingredients might damage the product.
- 5. Before you use a new essential oil, please follow the maintenance instruction and clean the product.
- 6. Please pour out remaining water if the product is not used for a long time.
- 7. Take care to wipe away any water droplets that accidentally stick to the surface of the device to prevent damage and corrosion.

- Software Installation

- 1. Download the Meross app.



- 2. Plug MOD150 into an outlet near home Wi-Fi.*



* Proximity to home Wi-Fi is required only during the initial setup process.
* MOD150 only supports 2.4GHz networks.

- 3. Set up the device.

- 1. Connect your smartphone or tablet to a 2.4 GHz Wi-Fi network.
- 2. Make sure your smart device is covered by strong Wi-Fi signal.
- 3. The smart device supports iOS 13/ iPadOS 13 and later. It is recommended that you upgrade your iOS or iPadOS to the latest version before pairing with the smart device.
- 4. Launch the Meross app and log in to your account, or if you are a new user, tap Sign up to create a new account.
- 5. Tap the “+” icon to select the type of smart device you want to add, then you can just follow the setup wizard to finish configuration.
- 6. Relocation of the smart device does not require additional operations provided that it remains on the same network with strong Wi-Fi signal.

NOTE:

- 1. If this is not the first time you've added this smart device, you'll have to reset it before going any further— press the power button and hold for 5 seconds until the LED flashes green.
- 2. As long as you finish configuration, you'll be able to manage the device in Apple Home app.
- 3. If the QR code does not work, please try to add the smart device in Apple Home app.
- 4. Find more at <https://www.meross.com/support>.

Link Meross to Google Assistant or Amazon Alexa

Set up the device in the Meross app first and then link it to voice assistants.

Link to Amazon Alexa

Go to Account-> Amazon Alexa and allow Meross to link with Alexa.

Link to Google Assistant

Go to Account-> Google Assistant and follow the step-by-step instructions to complete the linking process.

Amazon Alexa:

Example commands are as follows:

- "Hi Alexa, turn off/on the device."
- "Hi Alexa, turn off/on the light of the device."

Google Assistant:

Example commands are as follows:

- "Hey Google,turn off/on the device."
- "Hey Google, turn off/on the light of the device."

HomeKit Siri:


Example commands are as follows:

- "Hey Siri, turn off/on the device."
- "Hey Siri, turn off/on the light of the device. "

Maintenance

Clean the water tank every 3~5 days or when you want to use a new essential oil. Please follow steps below.

- 1. Unplug the power adapter and power cable, and then detach the cover.
- 2. Pour out remaining water from the right side as shown in the picture below.
- 3. Clean the water tank with a small amount of warm detergent. Wipe and dry the product with a swab. Do NOT use acid or enzymes detergent. Do NOT soak the product in water or let water go into the product.



meross

USER MANUAL

SIMPLE DEVICE
SIMPLIFY YOUR LIFE

Email: support@meross.com
Website: www.meross.com

Manufacturer: Chengdu Meross Technology Co., Ltd.
Address: No. 1312, Building E6-1, Tianfu Software Park, Chengdu, China



■ FAQ

At Meross, we strive to assure your satisfaction. Attached below is a non-exhaustive list of questions that users are mostly concerned about.

1. My diffuser can't be switched on.

- (a) Both the ambient light and the sprayer can not be switched on. Please ensure that the power cable was plugged properly.
- (b) The ambient light can be turned on, but the sprayer can not be turned on. Please ensure that there's enough water in the water tank.

If your power adapter is plugged in properly and the water tank has enough water in it, yet your diffuser refuse to work, please contact us and we will help you figure it out.

2. The spray is too weak and can not be switched to stronger mode.

It depends on water you use, temperature and humidity of the environment, and air flow in your room. Please try pure water, tap water, or distilled water to find the one best suit your diffuser.

3. How do I manage my Meross device in Apple Home app?

Your Meross smart device will be automatically added to Apple Home app after you finish configuration in the Meross app.

4. Why is my Meross smart device not responding in Apple Home app?

You can tap "Don't Have a Code or Can't Scan" and input the code manually.

To learn more, you can visit <https://www.meross.com/support/faqs> to find solutions for more frequently asked questions.

■ Warranty

Meross products are covered by a 12-month limited warranty from the date of purchase. Please visit <https://www.meross.com/support/warranty> for detailed warranty policy and product registration.

■ Disclaimer

1. The function of this smart device is tested under a typical circumstance described in our specifications. Meross does NOT guarantee that the smart device shall perform exactly the same as described under all circumstances.
 2. By using third-party services including but not limited to Amazon Alexa, Google Assistant, Apple HomeKit and SmartThings, customers acknowledge that Meross shall not be held liable in any way for the data and private information collected by such parties. Meross's total liability is limited to what is expressly covered in its Privacy Policy.
 3. Damages arising from ignorance of the SAFETY INFORMATION shall not be covered by Meross aftersales service, nor does Meross take any legal responsibility therefrom.
- Customers acknowledge understanding of these articles clearly by reading this manual.

■ Canadian Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- 1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre.

■ FCC Compliance Information Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.