



User Manual

■ **Safety Information**

RISK OF ELECTRIC SHOCK OR BURNS.

- Make sure the power is OFF on the bulb you are replacing.
- Wait until the bulb cools down and then replace it.
- Do not install the bulb with wet hands or when standing on wet or damp surfaces.
- Suitable for use in operating environment between -20°C and 40°C (- 4°F and 104°F).
- Not for emergency lighting.

■ **Installation Guide**

1. Download the Meross app.



2. Swap the current bulb with your Meross smart bulb.*



* Metal lamp shades may decrease your Meross smart bulb's performance.

3. Set up the device.

- (1) Make sure your smart bulb is covered by strong Wi-Fi signal.
- (2) Launch the Meross app, and log in to your account, or if you are a new user, tap Sign up to create a new account.
- (3) Tap the “+” icon to select the type of smart device you want to add, then you can just

follow the setup wizard to finish configuration.

Note:

Should you have any question, please visit <https://www.meross.com/support/>.

■ LED Rules



Flashing 3 times:

Initialization process finished, entering into configuration mode.

Smoothly flashing 2 times:

Successfully configured. (For MSL100 & MSL110 only)

Smoothly flashing from Red to Green to Blue to Warm to Cold white:

Successfully configured. (For MSL120 only)

■ FAQ

At Meross, we strive to assure your satisfaction. Attached below is a non-exhaustive list of questions that users are mostly concerned about.

1. How do I reset my Meross smart bulb?

Turn the light switch controlling the bulb to OFF first, then flip the light switch on and off 5 times.

Note that factory reset the smart bulb will erase all of your custom settings, and you'll have to set it up again.

2. Can I dim my Meross smart bulb with standard in-wall dimmer?

No. Meross smart bulb does not support standard in-wall dimmer. You can dim it via Meross app.

■ **Warranty**

Meross products are covered by a 12-month limited warranty from the date of purchase. Please visit <https://www.meross.com/support/warranty> for detailed warranty policy and product registration.

■ **Disclaimer**

1. The function of this smart device is tested under a typical circumstance described in our specifications. Meross does NOT guarantee that the smart device shall perform exactly the same as described under all circumstances.
2. By using third-party services including but not limited to Amazon Alexa, Google Assistant, Apple HomeKit and SmartThings,

customers acknowledge that Meross shall not be held liable in any way for the data and private information collected by such parties. Meross's total liability is limited to what is expressly covered in its Privacy Policy.

3. Damages arising from ignorance of the SAFETY INFORMATION shall not be covered by Meross aftersales service, nor does Meross take any legal responsibility therefrom.

Customers acknowledge understanding of these articles clearly by reading this manual.

FCC Compliance Information Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can

radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is

connected

- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canadian Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and

Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de

brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

SIMPLE DEVICE SIMPLIFY YOUR LIFE

Email: support@meross.com

Website: www.meross.com

Manufacturer: Hengdian Group Tospo Lighting Co. Ltd.

Address: Hengdian Electronics Industrial Zone, Dongyang, Zhejiang,
322118 China.



CAN ICES-3 (B)/NMB-3(B)



MADE IN CHINA
INDOOR USE ONLY