



■ Safety Information


1. The device is recommended for use indoors and in a dry location only.
2. The device shall be used within its published power rating on the instructions.
3. Please contact seller for replacement if there is any damage caused by transportation.
4. Please plug in the socket in proper condition and away from children.
5. Please plug in the socket fully while using for safety concern.

■ Installation Guide

1. Download the Meross app.




2. Plug MSS426 into an outlet near main Wi-Fi.*



- * MSS426 only supports 2.4GHz networks.
- * Proximity to main Wi-Fi is required only during the initial setup process.

3. Set up the device


1. Make sure your smart device is covered by strong Wi-Fi signal.
2. Launch the Meross app and log in to your account, or if you are a new user, tap Sign up to create a new account.
3. Tap the “+” icon to select the type of smart device you want to add, then you can just follow the setup wizard to finish configuration.
4. Relocation of the smart device does not require additional operations provided that it remains on the same network with strong Wi-Fi signal.



NOTE:

1. If this is not the first time you've added this smart device, you'll have to reset it before going any further.
2. Find more at <https://www.meross.com/support/>.

■ LED and Button Rules



■ FAQ

1. What devices can I control with the Smart Surge Protector?

You can control lights, fans, humidifiers, portable heaters and any small appliances in accordance with the MSS426's specifications (up to 13A output).

2. What if I can't control the smart device with the Meross app?

You can troubleshoot the following:

- Check if your home Wi-Fi is working properly.
- Make sure that you have disabled access control in your router and that the smart device is not blocked by the router's firmware.
- Factory reset your smart device and try to add it again.

■ Warranty

Meross products are covered by a 24-month limited warranty from the date of purchase. Please visit <https://www.meross.com/support/warranty> for detailed warranty policy and product registration.

■ Disclaimer

1. The function of this smart device is tested under a typical circumstance described in our specifications. Meross does NOT guarantee that the smart device shall perform exactly the same as described under all circumstances.
2. By using third-party services including but not limited to Amazon Alexa, Google Assistant, Apple HomeKit and SmartThings, customers acknowledge that Meross shall not be held liable in any way for the data and private information collected by such parties. Meross's total liability is limited to what is expressly covered in its Privacy Policy.
3. Damages arising from ignorance of the SAFETY INFORMATION shall not be covered by Meross aftersales service, nor does Meross take any legal responsibility therefrom. Customers acknowledge understanding of these articles clearly by reading this manual.

SIMPLE DEVICE SIMPLIFY YOUR LIFE

Email: support@meross.com

Website: www.meross.com

UK AR

CET PRODUCT SERVICE LTD. (for authorities only)
Beacon House Stokenchurch Business Park,
Ibstone Rd, Stokenchurch
High Wycombe HP14 3FE UK



Manufacturer: Chengdu Meross Technology Co., Ltd.
Address: No. 1312, Building E6-1, Tianfu Software Park,
Chengdu, China

MADE IN CHINA

INDOOR USE ONLY