


momcozy

7-IN-1 PORTABLE ELECTRIC BOTTLE BRUSH SET



User Manual

Thank you for purchasing this product. For the convenience of use, please read this manual carefully and keep it in a safe place. The pictures in the manual are for illustration only, and the actual product shall prevail.


Read all instructions before use

When using electrical products, especially when children are present, basic safety precautions should always be followed, including the following:
To reduce the risk of accidents: Do not place the charging cord where it can fall or be pulled into a sink. Do not place or drop the charging cord in water or other liquids. Do not reach for a charging cord/charger that has been dropped in water. Unplug the power cord immediately.

Warning: To reduce the risk of burns, accidents, fire, or personal injury, children must be closely supervised when using or approaching this product. Use this product only for the purposes described in this manual. Do not use accessories not recommended by the manufacturer. Do not operate this product if the power cord is damaged, the product does not function properly, the product has been dropped or damaged, or the charging cord has been dropped in water. Return the product to a service center for inspection and maintenance. Keep the cord away from heated surfaces. Not suitable for microwave sterilization

Important Check the cord regularly for damage, damaged or non-functional units should not be used.


Product content:




01

Equipment manual


1. Attach the required brush head to the handle
2. Soak the brush head in soapy water and then dip it into the bottle



3. Press the power button
4. Three brushes can thoroughly clean the baby's necessities




5. After cleaning, you can unfold the drain function to dry
6. The milk mixing stick is included for milk mixing



02

momcozy

Evolving for Mom and Cozy



Connection and charging

1. The brush is electrically safe and can be used without hesitation in the kitchen.
2. Plug the charging unit into a power socket. Connect the charging cable to the charging port on the handle. The handle must be turned off before starting charging.
3. In daily use, the handle can be plugged into the charging unit to keep the brush fully charged. Overcharging is not possible.

This product contains a rechargeable battery. If you wish to remove the battery yourself, please make sure to dispose of it in a safe and responsible manner at a dedicated battery unloading point.

MOMCOZY 7-in-1 portable electric bottle brush set is not suitable for microwave sterilization, the brush head is dishwasher safe, colors and styles may vary. BPA-free, IPX7 waterproof.

Product Name: 7-in-1 portable electric bottle brush set
Model Number: LS003
Batch Number:
Working Voltage: DC3.7V
Input: DC5V / 1.5A
Battery Capacity: 1800mAh
Host size: 35.3*35.3*193mm
Storage box size: 146.9*80.9*203.5mm

Manufacturer: Hong Kong Lute Technology Co, Limited
Address: Room 02, 21/F, Hip Kwan Commercial Building, 38 Pitt Street, Yau Ma Tei, Kowloon, Hong Kong

US Importer:
Company: ROOT TECHNOLOGY LTD.
Address: 1624 Market St Ste 226 #30327 Denver, Colorado, 80202, UNITED STATES
E-mail: support@momcozy.com




04

7. Host: Please clean the host and store it in a dry environment, away from high temperature and open flame.




8. Sponge brush head: After thoroughly rinsing the foam, drain and store it in a dry environment



9. Silicone brush head: Regularly detach the silicone brush head from the rod for cleaning. After thoroughly rinsing the foam, drain and store it in a dry environment



10. Storage box: Disassemble the lid and base of the storage box, clean them regularly, and ensure they are fully dry before reassembly and storage.



Notice: Clean each part after each use and wash off the foam thoroughly.

03