




Flex

Diaper Pail



KEEP FOR FUTURE REFERENCE


Please read the instructions carefully before using this product.

 IMPORTANT SAFEGUARDS	
Important Safeguards.....	3
 INCLUDED PARTS	
Included Parts.....	4
 HOW TO USE	
How To Use	5
Diaper Pail Refill Rings	6
Snap, Seal & Toss™ Bags	8
Compatible Refills.....	9
How To Clean	9
 CUSTOMER SERVICE	
One-Year Limited Warranty	10
Contact Us	10
To Order Refills.....	10


PLEASE READ ALL INSTRUCTIONS BEFORE USE

- Clean and inspect before use. This is not a toy; for adult use only. Close attention is necessary when used by or near children.
- Keep refill rings and Snap Seal & Toss™ bags out of reach of children.
- Use only as described in this manual.


INCLUDED PARTS



Diaper Pail



Refill Ring




**Snap, Seal
& Toss™ Bag**


- | | |
|---------------------|----------------------------|
| 1 Top Lid | 4 Simple Seal Flaps |
| 2 Inner Lid | 5 Bottom Lid |
| 3 Refill Bay | 6 Cutter |

HOW TO USE




1. Press and release the top lid to open.



2. Roll the used diaper tightly and push it through the Simple Seal flaps into the pail. Keep the lid closed to limit odors.



TIP: If there is any visible gap forming from where you insert the diaper, lift the bottom lid a few inches to release tension and close the gap. Repeat, as necessary. Change the bag when the odor control Simple Seal flaps no longer close.




NOTE: For best results, empty the diaper pail regularly and keep clean.


Do not use diaper pail to dispose of anything other than diapers.

DIAPER PAIL REFILL RINGS


1. Press and release the top lid to open.
Raise the inner lid.



2. Pull the film down through the ring's center. Tie a knot near the end to create a bag.




3. Place the ring into the refill bay, then feed the film through the Simple Seal flaps.




4. Lift the bottom lid, then pull the film all the way to the bottom of the pail. About 3 inches of material should rest on the floor of the pail. Lower the bottom lid and inner lid.

The diaper pail is now ready for use.




TO REMOVE FULL BAG


1. Lift the bottom lid to access the bag. Gather the film together near the top of the bag, then guide it into the cutting slot.



2. Pull firmly against the cutter to cut the film. Remove the bag from the pail and tie a knot to seal the bag.




3. Tie a knot near the end to create another bag.




4. Pull fresh film down to the bottom of the pail. About 3 inches of film should rest on the floor of the pail. Lower the bottom lid.

The diaper pail is now ready for use.




SNAP, SEAL & TOSS™ BAGS

1. Press and release the top lid to open. Raise the inner lid.




2. Place the Snap, Seal & Toss™ bag into the refill bay.

NOTE: Install the bag horizontally, in the same orientation as the Simple Seal flaps.




3. Lift the bottom lid, then feed the bag through the Simple Seal flaps into the pail. Lower the bottom lid.




4. Unfold and flatten the refill ring and press the tabs of the ring into the corner sockets to lock into position. Lower the inner lid.

Diaper pail is now ready for use.



TO REMOVE FULL BAG

1. Open the top and inner lids. Snap the plastic ring closed and push it down through the Simple Seal flaps. Remove and replace with a new bag.



COMPATIBLE REFILLS

The diaper pail is compatible with the following refill rings: Munchkin® Arm & Hammer™*, Up & Up®, Parent's Choice™*, Nursery Fresh®, and Comforts™.

The diaper pail also accepts Munchkin® Arm & Hammer™ Snap, Seal & Toss™ Bags.



Scan QR code for all compatible refills.
Not compatible with Diaper Genie refills.

HOW TO CLEAN

Wipe all surfaces of the diaper pail with clean damp cloth.

* Arm & Hammer is a trademark owned by Church & Dwight Co., Inc., licensed by Munchkin, Inc. Parent's Choice is a trademark owned by Walmart Apollo, LLC.



ONE-YEAR LIMITED WARRANTY

Munchkin's Diaper Pail includes a 1-year limited warranty against defects from the date of purchase. In the event of a malfunction or defect during the in-warranty period, Munchkin, Inc. at its option, will replace or repair the product under warranty. Upon receipt of the product and proof of purchase with a valid date of purchase, the defective part will be immediately repaired or replaced and returned to you free of charge (USA only). Please send defective unit, proof of purchase and a description of the problem you have encountered to:

Munchkin, Inc.
7835 Gloria Avenue
Van Nuys, CA 91406 USA
Attn: Diaper Pail Warranty

NOTE: This warranty does not cover misuse, abuse, abnormal wear & tear, negligence, environmental exposure, alteration or accident. Any alteration or removal of the product date code invalidates all claims against the manufacture.

CONTACT US

If you have any questions or wish to provide comments about this product, feel free to contact our Customer Satisfaction team at **1-800-344-BABY** (2229) (M-TH 8:00am-5:00pm PST, F 8:00am-1:00pm PST) or visit our website at **www.munchkin.com**.

TO ORDER REFILLS

Visit our website at **www.munchkin.com**.



munchkin.com
800.344.2229

