





Install camera batteries




Slide latch to remove
battery door.



What's in the box



Go to <http://support.netgear.com> for support help.



We're here to help!

Go to <http://support.netgear.com> for product updates and web support.

You can also access support by clicking the **Help** link when logged into your account at my.VueZone.com

Visit VueZone.com

NETGEAR, Inc.
350 East Plumeria Drive
San Jose, CA 95134 USA



201-15803-04

NETGEAR
vuezone

©2013 NETGEAR, Inc. All rights reserved. NETGEAR, VueZone and the NETGEAR VueZone logo are trademarks or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries.

Adding a VueZone Camera



NETGEAR
vuezone



2

Sync cameras

Click the Sync button on top of base station.

Blue Sync light will turn on.

Hold camera within 12 inches of the base station and slide power switch ON (green dot showing).

Blue light on camera front will blink for 5 seconds to confirm sync.



NOTE: each time power is turned ON, motion detection cameras require 1 minute for sensor to warm up and operate.

4

Start viewing!

Synced cameras will appear on the **Cameras** tab on your account at **my.VueZone.com**.

Click ► on the camera or on the toolbar to start viewing.

Aim cameras from your smartphone with VueZone Mobile. For complete details, go to VueZone.com/mobileapps

3

Install cameras

Peel.

Remove strip from adhesive backing on mount. Do not remove if mounting on a screw.



Stick.

Press mount firmly on a flat surface or hang from a screw.



Position.

Place the camera on the magnetic mount and aim.



Mounts for windows and tabletops/ceilings are also available at VueZone.com

Declaration of Conformity

For the complete EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a_id/11621/

**Warning: Choking hazard with small parts.
Keep out of reach of small children.**