

Get Started

All you need to know to get going.

NETGEAR®
LTE GATEWAY 6100D

Sprint



Welcome!

Thanks for choosing Sprint. This guide introduces you to the basics of getting started with Sprint and your NETGEAR® LTE Gateway 6100D.


ReadyNow – For more help in getting up and running with your new device, take advantage of exclusive **Ready Now** resources at sprint.com/readynow. You can even schedule a one-on-one appointment at a Sprint Store near you.

For ongoing support and resources, visit sprint.com/support. There, you'll find guides, tutorials, and more to help you get the most out of your device.


Note: Available applications and services are subject to change at any time.

©2013 Sprint. Sprint and the logo are trademarks of Sprint. NETGEAR, and the NETGEAR logo are trademarks of NETGEAR, Inc. in the United States and/or other countries. Other marks are property of their respective owners.

What's in the Box



Your LTE Gateway 6100D



Settings


When connected to the Gateway network, you can use a Web browser to log in to your Gateway to view or change its settings. You can:

- Activate your account if it did not automatically activate.
- View your data usage and status information for your data connection.
- Manage your mobile broadband network connection and Wi-Fi connections.
- View alert messages, and more.

Log In to Your Gateway

1. On a computer or wireless device that is connected to your Gateway's network, launch a Web browser.
2. In the address or URL field of your browser, type <http://myrouter> (or <http://192.168.0.1>).

3. When prompted to log in, enter **admin** for the user name and type the password. (The default password is **password**).



For detailed information about settings, please see the **User Guide** at sprint.com/support.

Before You Start

System Requirements

The following items are required to use your LTE Gateway 6100D:

- One or more computers that support Wi-Fi (802.11 a/b/g/n or 802.11ac or 802.11 a/b/g/n/ac)
- Web browser (required if you'll be using the browser interface to view status and to configure settings). The following browsers are supported:
 - Internet Explorer (version 8 and above)
 - Firefox (version 3.6.24 and above)
 - Chrome (version 30 and above)
 - Safari (version 5.1.7 and above)
- If you'll be connecting to your Gateway through Ethernet:
 - Computer with an available Ethernet port

Attach the Antennas

The Gateway comes with two external antennas that are interchangeable. For best performance, connect both antennas.

1. Align the antennas with the antenna posts on the router.
2. Attach the antennas on the threaded antenna posts, ensuring that the connection is secure.
3. Adjust the antennas so that they are vertical.

Place Your Gateway

1. Place your Gateway in a location that receives a strong wireless signal, such as near a window.
2. Use the Signal Quality LED to position the Gateway for the best signal strength.

Manage Your Account

Online: www.sprint.com

- Make a payment, see your bills, enroll in
- online billing.
- Check usage and account balance.
- See or modify the details of your Sprint service plan.
- Get detailed instructions and download content.

From a Phone

- Sprint Customer Service: Dial **1-888-211-4727**
- Business Customer Service: Dial **1-888-788-4727**



BV-COC-115926

Sustainability

At Sprint, environmental responsibility is more than talk. We're continuously working to reduce our carbon footprint and decrease our use of natural resources.

So where is my User Guide?

To support our increased responsibility efforts, we've put expanded instructional materials online for you. Just visit sprint.com/support from any computer to access your complete User Guide and other support materials.

What else has Sprint been doing?

Plenty. To find out just what we've been up to, visit sprint.com/green.

This guide is printed with vegetable inks and contains up to 40% post consumer paper.

Get Connected

Start Your Gateway for the First Time

The Gateway is designed to activate automatically the first time that it is turned on using 'hands-free activation'.

1. Connect the power adapter to the Gateway and plug the power adapter into an electrical outlet.
2. Make sure that the Power On/Off button on the rear panel of the Gateway is pressed in.

If your Gateway is still not activated, visit sprint.com/support for assistance. If you do not have access to the Internet, call Sprint Customer Service at **1-888-211-4727**.

Connect to Your Gateway's Network

You can connect with Wi-Fi or you can use an Ethernet Cable for a wired connection.

Wi-Fi:

1. On your computer or wireless device, open the software or application that manages wireless connections. (Please see the user documentation for your operating system or computer.)
2. Select the Wi-Fi network for the Gateway and connect to it. (If prompted for a network security key/password, enter the Wi-Fi password located on the Gateway label.)

Ethernet Cable:

1. Connect an Ethernet Cable (included) to one of the yellow Ethernet LAN ports on the rear panel of the Gateway.
2. Connect the other end of the Ethernet Cable to an Ethernet port on your computer.

Resources

- **User Guide** – View the comprehensive User Guide online at sprint.com/support.
- **Ready Now** – Visit sprint.com/readynow for additional help to get started on your new device. You'll find more information on basic setup, activation, maximizing performance, and personalization.
- **Community** – Visit community.sprint.com to join the discussion about all things Sprint. Here people help each other make the most of their services with tips, forums, blogs, and the latest news.
- **Online Support** – Go to sprint.com/support to access troubleshooting and other resources, or go to sprint.com/downloads to download updates.

Feedback

Please tell us what you think about your new device.

We are interested in your initial impressions of this new Sprint device. Within two weeks of your device purchase, please go to <http://labs.sprint.com/sprintphonesurvey> to complete a brief survey. Your feedback will help us provide the wireless features and services you want most.

Thank you for choosing Sprint.



201-17792-01

¡Bienvenido!

Gracias por elegir Sprint. Este folleto te introduce a lo básico para empezar a usar Sprint y tu nuevo NETGEAR® LTE Gateway 6100D.


ReadyNow – Para obtener más ayuda en optimizar e iniciar tu nuevo equipo, aprovecha los recursos del exclusivo **Ready Now** en sprint.com/readynow¹. Podrás incluso programar citas en tu tienda Sprint más cercana.

Para obtener apoyo y recursos, visita sprint.com/support¹. Allí encontrarás guías, tutoriales y más para sacar el máximo provecho a tu equipo.

Nota: Los servicios y las aplicaciones disponibles están sujetos a cambio.

¹ Disponible sólo en inglés.
©2013 Sprint. Sprint and the logo are trademarks of Sprint. NETGEAR, y el logotipo NETGEAR son marcas comerciales de NETGEAR, Inc. en EE.UU. y otros países. Otras marcas son propiedad de sus respectivos propietarios.

Tu LTE Gateway 6100D



Antes de comenzar

Requisitos del sistema

Se requiere lo siguiente para usar tu LTE Gateway 6100D:

- Una o más computadoras que utilicen el navegador de Web por Wi-Fi (requerido si vas a utilizar la interfaz del navegador para ver el estado y configurar). Los siguientes navegadores son utilizados:

- Internet Explorer (versión 8 y mayor)
- Firefox (versión 3.6.24 y mayor)
- Chrome (versión 30 y mayor)
- Safari (versión 5.1.7 y mayor)

- Si vas a conectar tu Gateway a través de Ethernet:

- Computadora con un puerto Ethernet disponible

Maneja tu cuenta

En Internet: www.sprint.com

- Realiza un pago, revisa tus facturas, suscríbete a facturación por Internet

- Revisa el uso y el saldo de tu cuenta
- Revisa o modifica los detalles de tu plan de servicio Sprint

- Obtén instrucciones detalladas y descarga contenido

Desde un teléfono

Atención al Cliente Sprint:

Marca 1-888-211-4727

- Atención al Cliente para Negocios:

Marca 1-888-788-4727



BV-COC-115926

¹ Disponible sólo en inglés.

Para obtener información detallada acerca de la ajustes, consulte la **Guía del Usuario** en sprint.com/support¹.

Configuraciones

Cuando estés conectado a la red Gateway,

podrás usar un navegador de Web para conectarte a tu Gateway para ver o cambiar tus configuraciones. Puedes:

- Activar tu cuenta si no activaste automáticamente.

- Ver el uso de tus datos e información del estado para tu conexión de datos.

- Manejar tu conexión de la red de banda ancha móvil y conexiones Wi-Fi.

- Ver mensajes de alerta, y más.

Inicia una sesión en tu Gateway

1. Usando una computadora o dispositivo inalámbrico conectado a tu red de Gateway, inicia tu navegador de Web.
2. En el campo de dirección o URL en tu navegador, ingresa <http://myrouter.sprint.com>.

Sostenibilidad

En Sprint, la responsabilidad con el medio ambiente es más que habladurías. Trabajamos continuamente para reducir nuestro impacto de carbono y reducir nuestro uso de recursos naturales.

En un intento por aumentar nuestros esfuerzos de responsabilidad, hemos puesto materiales educativos expandidos en Internet para ti. Visitar sprint.com/support¹ desde cualquier computadora para encontrar su guía de usuario completa y más.

¿Qué más ha estado haciendo Sprint?

Muchos recursos. Para saber exactamente lo que estamos haciendo, visita sprint.com/green¹ para más información. Esta guía está impresa con tintas de verduras y contiene hasta un 40% de papel de postconsumo.

¹ Disponible sólo en inglés.

Recursos

- **Guía del Usuario** – Consulte la Guía del Usuario completa en línea en sprint.com/support¹.
- **Ready Now** – Visita sprint.com/readynow¹ para obtener ayuda adicional y así comenzar a usar tu nuevo equipo. Encontrarás más información sobre la configuración básica y activación, maximizando el rendimiento y personalización de tu equipo.

• **Comunidad** – Visita community.sprint.com¹ para unirte a las discusiones acerca de todo lo relacionado con Sprint. Allí la gente colabora mutuamente para sacar el máximo provecho de nuestros servicios móviles, con consejos, foros, blogs, y las últimas noticias.

- **Apoyo en línea** – Visita sprint.com/support¹ para acceder a la sección de solución

visite sprint.com/downloads¹ para descargar actualizaciones.

Encuesta

Por favor díinos lo que tú piensas

de tu nuevo equipo. Estamos interesados en tus impresiones iniciales de este nuevo equipo Sprint. Dentro de las dos semanas a partir de la compra de tu equipo, por favor ve al sitio de Internet <http://labs.sprint.com/sprintphonesurvey>¹ para completar una breve encuesta. Tu respuesta nos ayudará a proveer las funciones y servicios móviles que más quieras.

Gracias por elegir Sprint.

¹ Disponible sólo en inglés.

Conéctate

Enciende tu Gateway por primera vez

1. En tu computadora o dispositivo inalámbrico, abre el software o aplicación que maneja las conexiones inalámbricas. (Favor de ver la documentación del usuario para tu sistema operativo o computadora.)
2. Selecciona la red Wi-Fi para la Gateway y conéctate a la misma. (Si te pide una clave de seguridad/contraseña de la red, ingresa la contraseña de Wi-Fi ubicada en la etiqueta de la Gateway.)
1. Conecta un Cable Ethernet (incluido) a uno de los puertos en amarrillo de Ethernet LAN en el panel trasero de la Gateway.
2. Conecta el otro extremo del Cable Ethernet a un puerto Ethernet en tu computadora.

Cable Ethernet:

Si tu Gateway aún no está activada, visita sprint.com/support¹ para asistencia. Si no tienes acceso a Internet, llama a Servicio al Cliente de Sprint al 1-888-211-4727.

Puedes conectar con Wi-Fi o puedes usar un Cable Ethernet para conectar por cable.

Conecta a la red de tu Gateway

Puedes conectar con Wi-Fi o puedes usar un Cable Ethernet para conectar por cable.

1. Conecta el adaptador de corriente a la Gateway y enchúfalo a un enchufe eléctrico.
2. Asegúrate de que el botón de encendido (On/Off) en el panel trasero de la Gateway esté presionado hacia adentro.


Si tu Gateway aún no está activada, visita sprint.com/support¹ para asistencia. Si no tienes acceso a Internet, llama a Servicio al Cliente de Sprint al 1-888-211-4727.

NETGEAR®
LTE GATEWAY 6100D



Todo lo que tienes que saber para empezar.

Vamos



Contenido de la caja