

Nighthawk® 5G Mobile Hotspot



Let's Get Started

AT&T Eco Rating 2.0 only applies to the NETGEAR Nighthawk 5G Mobile Hotspot, model M5000. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

NETGEAR and Nighthawk are trademarks of NETGEAR, Inc. 5G is a trademark of 3GPP. 5G not available everywhere. Contains Lithium ion battery - recycle or dispose of properly.

© 2018 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.


Printed in USA

201-24405-01

What's in the Box

- Nighthawk 5G Mobile Hotspot with pre-installed SIM card
- Battery cover
- Battery
- USB Type-C cable
- AC adapter
- Quick start guide

Get to Know Your Mobile Hotspot



Install the Battery

- 1 Insert the battery.



- 2 Install the back cover.

The battery is partially charged. To fully charge it, connect the USB cable to the mobile hotspot and then plug into either:


- A wall socket, using the wall charger (faster charge option)
- The USB port on your laptop

Note: The mobile hotspot comes with a preinstalled SIM card. The SIM must be activated to a data plan with AT&T.


Set Up Your Mobile Hotspot

- 1 Press and hold the **Power** button for 2 seconds.

To better safeguard your network, the first time you turn on your mobile hotspot, you are asked to set up your login credentials.



- 2 Follow the onscreen instructions to customize your mobile hotspot settings.



Connect to the Internet



On your laptop or other WiFi device

- 1 Open your WiFi network connection manager.
- 2 Find your mobile hotspot's WiFi network name (ATT-WIFI-XXXX) and connect.
- 3 Enter your mobile hotspot's WiFi password.
- 4 Launch your Internet browser.

Note: The screen goes dark to save power. Press and release the **Power** button to wake the screen.

LCD Screen

When the Lock screen displays, swipe up to go to the Home screen.




The network indicator lets you know which AT&T wireless network you are connected to.

LCD WiFi Manager


You can manage the WiFi network from the LCD screen.

Change the WiFi network name and password

- 1 On the home screen, tap the **WiFi** icon.



- 2 Tap **Main WiFi**.



- 3 Enter your changes.


Change the WiFi band

- 1 On the home screen, tap the **WiFi** icon.
- 2 Tap **Band**.
- 3 Select the 2.4 GHz or 5 GHz WiFi band.

LCD Settings

View or change the settings

On the home screen, tap the **Settings** icon.



For More Information

Manage your account

On the web: att.com/my ATT

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need more help?

On the web: att.com/DeviceHowTo

Or go to <http://192.168.2.1:8080/>, click the ... icon in the upper right corner.

Give us a call

611 from any AT&T wireless phone, or 800.331.0500. When prompted, enter your device's 10-digit number. (To get the number, go to <http://192.168.2.1:8080/> and click **Dashboard**.)

WiFi Manager

You can use a browser to view and change the mobile hotspot settings.

Log In

- 1 On your WiFi device, type <http://192.168.2.1:8080/> in the browser bar.
- 2 Log in as administrator.

The default login is **attadmin**.

