

En Features available with “C” firmware version 1.60

The *Z fc Reference Guide* is for “C” firmware version 1.50. This supplement details the new features and changes introduced with camera “C” firmware version 1.60. The two documents are to be read together.

“Firmware version”


To view the camera firmware version or update the camera firmware, select [**Firmware version**] in the setup menu.

Updates can be performed using a computer or smart device.

- **Computer:** Check the Nikon Download Center for new versions of the camera firmware. Information on performing updates is available via the firmware download page.
<https://downloadcenter.nikonimglib.com/>
- **Smart device:** If the smart device has been paired with the camera using the SnapBridge app, the app will automatically notify you when updates become available, and you can then download the update to the camera memory card via the smart device. For information on performing updates, see SnapBridge online help. Note that automatic notifications may not be displayed at exactly the same time as the updates are made available on the Nikon Download Center.

New Custom Setting: g7 “Red REC frame indicator”

[Red REC frame indicator] has been added as Custom Setting g7. If [On] is selected, a red border will appear around the shooting display while video recording is in progress. This helps prevent missed shots by alerting you when recording is in progress.



New option for the setup menu “Information display”: background colors

Setting items [1] to [12] have been added to the setup menu [Information display]. Setting one of the items from [1] to [12] will set the background of the information display to the color displayed next to the item name.

New option for the setup menu: “Welcome screen”

A [Welcome screen] has been added to the setup menu. Setting this option to [On] will display a welcome screen animation when the camera is turned on. The welcome screen will switch between a variety of animations.