

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.



PROFESSIONAL
KITCHEN SYSTEM

QUICK START GUIDE


BEFORE FIRST USE

IMPORTANT: Review all warnings at the beginning of this Owner's Guide before proceeding.

- 1 Remove all packaging materials from the unit. Exercise care when unpacking the Stacked Blade Assembly, Chopping Blade Assembly and Pro Extractor Blades® Assembly as the blades are sharp.
- 2 The Chopping Blade Assembly and Stacked Blade Assembly are **NOT** locked in place in their containers. Handle the Chopping Blade Assembly and Stacked Blade Assembly by grasping the top of the shaft.
- 3 Handle the Pro Extractor Blades Assembly by grasping around the perimeter of the blade assembly base.
- 4 Wash containers, lids, and blade assemblies in warm, soapy, water using a dishwashing utensil with a handle to avoid direct contact with the blades. Exercise care when handling blade assemblies, as the blades are sharp.
- 5 Thoroughly rinse and air-dry all parts.
- 6 Wipe control panel with a soft cloth. Allow it to dry completely before using.

NOTE: All attachments are BPA free and dishwasher safe. It is recommended that the containers, lids, and blade assemblies be placed on the top rack of the dishwasher. Ensure blade assemblies and lids are removed from the containers before placing in the dishwasher. Exercise care when handling blade assemblies.

FEATURES





Use the Power button to turn the unit on or off

LOW | MEDIUM | HIGH

When selected, each of these speeds will continuously run for 60 seconds. Press the currently active button again to stop the program sooner. These programs do not work in conjunction with the Max program.

MAX

Turn ice, juices, and fruit into expertly blended frozen drinks.


PULSE

Offers greater control of pulsing and blending. Operates only when PULSE is pressed. Use short presses for short pulses and long presses for long pulses.

NOTE: The unit can detect which container is installed on the motor base. Only the functions available for a particular container will illuminate on the control panel.

TOTAL CRUSHING® PITCHER


PARTS




ASSEMBLY



1. Place the Total Crushing Pitcher on base and turn clockwise to lock in place.



2. Holding Stacked Blade Assembly by the top of the shaft, insert it into pitcher.




3. Align arrows on pitcher lid and handle, then lower handle to lock in place.


BLEND & ENJOY




1. Select any of the illuminated programs to begin.



2. When blending is complete, turn pitcher counterclockwise and lift to remove.



3a. To pour out thinner mixtures, ensure lid is locked in place, then open pour spout.



3b. For thicker mixtures, press RELEASE button and lift handle to remove lid, then carefully lift out blade assembly before pouring.

NOTE: The pitcher lid handle will not fold down unless it is attached to the pitcher.

Once the Total Crushing Pitcher is locked onto base, press the Power button  to turn the unit on. The compatible program buttons will illuminate.

WARNING: Stacked Blade Assembly is sharp and not locked in place. Make sure lid is locked onto pitcher before pouring contents. If pouring without lid, carefully remove blade assembly first. Failure to do so will result in a risk of laceration. Refer to the Ninja Owner's Guide for additional information.

SINGLE-SERVE CUP

PARTS



MOTOR BASE



SINGLE-SERVE CUP




SPOUT LID




PRO EXTRACTOR
BLADES® ASSEMBLY

ASSEMBLY



BLEND & ENJOY



Once the Single-Serve Cup is locked onto base, press the Power button  to turn the unit on. The compatible program buttons will illuminate.

PRECISION PROCESSOR™ BOWL

PARTS



MOTOR BASE



PRECISION PROCESSOR
BOWL




PRECISION PROCESSOR
BOWL LID




CHOPPING BLADE
ASSEMBLY

ASSEMBLY



BLEND & ENJOY



Once the Precision Processor Bowl is locked onto base, press the Power button  to turn the unit on. The compatible program buttons will illuminate.



WARNING: Chopping Blade Assembly is sharp and not locked in place. Before pouring, carefully remove blade assembly. Failure to do so will result in a risk of laceration. Refer to the Ninja Owner's Guide for additional information.



WARNING: Handle the Pro Extractor Blades Assembly with care, as the blades are sharp.

NOTES

[illegible]

NOTES

[illegible]



**For questions or to register your product,
visit us online at ninjakitchen.com**



@ninjakitchen

© 2025 SharkNinja Operating LLC.

NINJA, PRO EXTRACTOR BLADES, and TOTAL CRUSHING are registered trademarks of SharkNinja Operating LLC.

NINJA ULTRACRUSH and PRECISION PROCESSOR are trademarks of SharkNinja Operating LLC.

BP401_QSG_MP_Mv3