

Quick Setup Guide

DMR-EA18


Panasonic®



If you have any
questions contact
PANA
1-800-211-7262

Connection

Connecting to a TV and a Set Top Box




Connecting with an HDMI (High Definition Multimedia Interface) Cable

You can enjoy high-quality picture and audio by changing the audio/video (AV) cable connection between this unit and your TV (➡ left).

When connected to an HDMI compatible unit, an uncompressed digital audio and video signal is transmitted, enabling you to enjoy high quality digital video and audio with just one cable. When connecting to an HDMI-compatible HDTV (High Definition Television), the output can be switched to 1080p, 1080i or 720p HD video.

- Please use HIGH SPEED HDMI cables that have the HDMI logo (as shown on the cover of the operating instructions). It is recommended that you use Panasonic's HDMI cable.



- Set "HDMI Priority" and "HDMI Audio Output" to "On" (The default setting is "On".) (➡ pages 48 and 49 in the operating instructions).

■ VIERA Link™ "HDAVI Control™"

What is VIERA Link "HDAVI Control"?

VIERA Link™ is a new name for EZ Sync™.

VIERA Link "HDAVI Control" is a convenient function that offers linked operations of this unit, and a Panasonic TV (VIERA) or receiver under "HDAVI Control". You can use this function by connecting the equipment with the HDMI cable.

For details on the benefits of "HDAVI Control", please refer to pages 30 and 31 in the operating instructions.


Initial Settings

Preparing the TV and the set top box

1 Turn the TV and the set top box on.

2 Selecting the video input on your TV.

Activate the TV's video input which was connected to this unit. e.g. the TV/VIDEO or INPUT button




3 Turn this unit on.




- When this unit is connected to a Panasonic TV (VIERA) supporting HDAVI Control 3 and initially set up, it automatically acquires the TV setting information. For details, please refer to page 12 in the operating instructions.

4 Select the language.





- If you make a mistake, press [RETURN].



5 Select the type of TV you are using.



6 Set Quick Start to "On" or "Off".




10 Enter a channel that can be received by your set top box.




7 Select whether to control your set top box with this unit or not.



- If you select "No", you can proceed to "Set Clock Manually" (➡ Step 12, right).



11 Select "Yes, try other channels", "Yes, complete setup" or "No, try another code".



8 Select an item and change the STB (Set Top Box) IR Settings.



12 Select an item and change the setting.



9 Select "Test" to check the operation of the Set Top Box Control cable.



13 Complete the settings.



- To return to the previous screen



- Please refer to "Basic Operations" (pages 13 to 16) in the operating instructions.