


Panasonic

Easy Setting Guide

Blu-ray Disc™ Home Theater Sound System


Model No. **SC-BTT490**

STEP 1: Assembling the front speakers



STEP 2: Attaching the sticker to the speaker cables


e.g., Front speaker Lch




Speaker cable sticker	Connector
FRONT Lch ①	WHITE
FRONT Rch ②	RED
SURROUND Lch ③	BLUE
SURROUND Rch ④	GRAY
CENTER ⑤	GREEN
SUBWOOFER ⑥	PURPLE

STEP 3: Connecting the speaker cables

• Surround speakers have no difference between right and left.



STEP 4: Placing the speakers



If you have any questions contact

U.S.A. and Puerto Rico:

1-800-211-PANA (7262)

Mon-Fri 9 am–9 pm (EST) Lunes-Viernes

Sat-Sun 10 am–7 pm (EST) Sabado-Domingo

www.panasonic.com/help

Canada:

Telephone: 1-800-561-5505


E-mail link: "Support → contact us →

email" on www.panasonic.ca

STEP 5: Connecting the cables


For information on other connection methods and the internet features, refer to the Owner's Manual.

A video cable (not supplied) is required to view photos/videos on the iPod/iPhone.




STEP 6: Turning on the system

1 Connect the AC power supply cord.




2 Turn on the TV.



Set the video input mode to HDMI, etc.

3 Turn on the system.



4 The Easy setting starts.

Follow on-screen instructions.