

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PBLID04

DESCRIPTION

18V Brushless 4-Mode Impact Driver




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

9-25-24 (Rev:01)


The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	204381006	Housing Assembly (Inc Key Nos. 2-3)	1
2	941124569	Data Label	1
3	941120665	Battery Statement Label	1
4	206381002	Motor, Circuit Board and Pinion Assembly	1
5	680334044	Pin, DIA 2.5X46.4	2
6	611574081	Ring Gear	1
7	206381003	Gear Box Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
8	206381004	Gear Case Assembly	1
9	660187012	Screw (M3 x 22 mm, T10 Torx, Black)	4
10	541461001	Wire Cover	1
11	541257001	Forward/Reverse Button	1
12	662456001	Screw (M3 x 16 mm, T10 Torx, Black)	8
	Not Shown:		
	999000399	Operator's Manual	



WIRING DIAGRAM