

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

PCL510

DESCRIPTION

ONE+ 18V ONE-HANDED RECIPROCATING SAW




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

8-22-25 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.

RYOBI PCL510






PCL510

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	662565001	Screw (ST M3.5 x 14 mm, Torx Pan Hd.)	13
2	204784016	Housing Assembly (Inc. Key No. 16-17)	1
3	206687009	Motor & Switch Assembly	1
4	554668001	Trigger Lock Button	1
5	526010001	Pin (5 x 11 mm)	1
6	692177001	Spring (ID0.3 x OD3.3 x L14 mm)	1
7	660024030	Screw (M4 x 16 mm)	2
8	560760003	Rubber Cushion (5 mm)	8
9	661113008	Screw (#8-32UNC)	6
10	554669001	Gear Case Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
11	692240003	Sleeve (OD10 x ID5 x 8t)	1
12	206786016	Gear Box Assembly	1
13	318011003	Saw Bar Assembly	1
14	633628002	Stationary Shoe	1
15	690347002	Blade (10 TPI)	1
16	941124776	Data Label	1
17	941119398	Warning Label	1
	Not Shown:		
	999000561	Operator's Manual	



WIRING DIAGRAM