


REPLACEMENT PARTS LIST

BRAND RYOBI		DESCRIPTION 40V 300W POWER SOURCE AND BATTERY CHARGER
MODEL NO. RY40BG02	MFG. NO. 095930808	




TECHTRONIC INDUSTRIES POWER EQUIPMENT

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

4-17-26 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	940779764	LED Label	1
2	940168040	Powerstation Label	1
3	940168039	Warning Label	1
4	940168041	QR Code Label	1
5	940779550	Warning / Caution Label	1
6	941097412	Data / Icon Label	1
7	563684020	Rubber Foot A	2

KEY NO.	PART NO.	DESCRIPTION	QTY.
8	563684022	Rubber Foot B	2
9	290361174	USB-C USB Cable	1
10	720423036	100W Wall Adaptor (110V-240V AC)	1
	Not Shown:		
	999000535	Operator's Manual	