

REPAIR SHEET

BRAND

RYOBI

MODEL NO.


RY40SS01

MFG. NO.

315261009

DESCRIPTION

Straight Shaft Trimmer Attachment With 2-in-1 Head Accessory




TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

9-05-25 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.





RY40SS01

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	205840011	3-in-1 String Head Assembly	1
2	205827004	Grass Deflector Assembly (Inc. Key No. 21)	6
3	205840012	Bump Feed Trimmer Head Assembly	1
4	205840013	Fixed Line and Blade Housing Assembly	1
5	537603002	Flail (119 mm)	1
6	662568002	Flange Nut (M8 x 12.5 mm)	1
7	678011001	Flanged Washer	1
8	308210032	Gear Box Assembly	1
9	660642001	Screws (1/4-20 UNC x 1 1/4 in.)	1
10	660911001	Screw (M5 x 13 mm)	1
11	660738002	Screw	1
12	205671006	Lower Boom Assembly (Inc. Key Nos. 17-18 & 20)	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
13	205121018	Silicone Isolator Assembly	1
14	687650001	Compression Spring	2
15	660694001	Screw	2
16	638020006	Blade	1
17	941263550	Warning Icon Label	1
18	941851149	Expand-It Label	1
19	918013319	Reloading Instructions Hangtag	1
20	941263537	Data Label	1
21	941263549	Cutting Width Label	1
	Not Shown:		
	999000541	Operator's Manual	