

REPAIR SHEET

BRAND

RYOBI

DESCRIPTION


12 Volt Pruning Saw

MODEL NO.

TVCW01

MFG. NO.

096610001




TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

7-25-25 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



**TVCW01****PARTS LIST**

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	548772002	Battery Cover	1
2	281713001	Charging Port	1
3	660200005	Screw (M2.3 x 5 mm, Pan Hd.)	1
4	549050001	Grommet	1
5	205422002	Front Guard Assembly (Inc. Key No. 6)	1
6	205422003	Guard Hardware Pack	1
7	615229001	Sprocket	1
8	635367003	Washer	1
9	636159001	E Ring	1
10	319078001	Chain Tension Assembly	1
11	319086010	Sprocket Cover Assembly	1
12	318906008	Guide Bar	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
13	318908001	6 in. Saw Chain	1
14	545915002	Scabbard	1
15	660004019	Screw (M3 x 12 mm, Pan Hd.)	4
16	T663208001	Screw (M4 x 5.5 mm, Pan Hd.)	1
17	130768004	Battery Assembly	1
18	140526003	12V Charging Cable	1
19	941263506	Data Label	1
20	941263507	Icon/Warning Label	1
	Not Shown:		
	961087785	Manual	