



SIMRAD®

AD80 THRUSTER INTERFACE INSTALLATION GUIDE




Parts included



- A** 1x AD80 computer
- B** 1x Cable retainer
- C** 6x Mounting screws, 3.5 mm x 19 mm (DIN7981B)
- D** 10x Cable ties
- E** 8x Connectors
- F** 1x Micro-C drop cable (male)
- G** 1x Micro-C T-joiner

Dimensions




For technical specifications, certificates and declarations, refer to the product website:




www.navico-commercial.com


Mounting




System wiring



AD80 terminal layout




Grounding




Analog drives


VOLTAGE CONTROL LINE




CAN bus backbone




Central alarm panel




External I/O - Ready signal




External I/O - Handshake



Rudder feedback



External Mode selector - pulse



External System selector

