

**OH, THE WONDERFUL
THINGS YOU'LL MAKE!**

SISER CRAFT PRESS GO!
OPERATOR'S MANUAL

Certification Number: GMA-529926


SISER S.r.l.

Viale della Tecnica, 18
36100 VICENZA, ITALY
tel. +39 0444 287960
fax +39 0444 287959

info@siser.it - www.siser.com



**CRAFT
PRESS
GO!**



OPERATOR'S MANUAL




Reproduction, memorization and transmission of all and parts of this publication are prohibited in any form without the prior written authorization and consent of **SISER S.r.l.**

SISER S.r.l., with its policy of constant improvement and development of its products, reserves the right to alter the specifications, equipment and instructions for use and maintenance at any time and without notice.

OTHER LANGUAGES



Inquadra il QR Code per scaricare il manuale in Italiano.



Scannen Sie den QR-Code, um das Handbuch auf Deutsch herunterzuladen.

INDEX

Safety instructions	3
1. Part identification	4
1.1 Control Panel	5
2. Initial setup	6
3. Adjusting temperature, time and pressure	7
4. Applying with your press	9
5. Terms of Guarantee	11
5.1 Warranty policy	
5.2 Liability	
5.3 CE certification - reference standards	
6. Retiring the machine, demolition and disposal	12


Safety instructions

When using your heat press, basic precautions should always be followed, including the following:

1. Read all instructions.
2. Use heat press only for its intended use.
3. To reduce the risk of electric shock, do not immerse the heat press in water or other liquids.
4. Never pull cord to disconnect from outlet, instead, grasp plug and pull to disconnect.
5. Do not allow cord to touch hot surfaces, allow heat press to cool completely before storing.
6. Do not operate heat press with a damaged cord or if the equipment has been dropped or damaged. To reduce the risk of electric shock, do not disassemble or attempt to repair the heat press. Take it to a qualified service person for examination and repair. Incorrect assembly or repair could increase the risk of fire, electric shock, or injury to persons when equipment is used.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Close supervision is necessary for any heat press being used by or near children. Do not leave equipment unattended while connected.
9. Burns can occur when touching hot metal parts.
10. To reduce the likelihood of circuit overload, do not operate other high voltage equipment on the same circuit.
11. If an extension cord is necessary, a 10 amperage rated cord should be used. Cords rated for less amperage may overheat. Care should be taken to arrange the cord so that it cannot be pulled or tripped over.
12. Do not attempt to open or remove the press control box yourself; if problems arise, contact our specialist person directly during normal working hours on +39 0444 287960. Opening the instrument box of your own accord causes all rights to warranty to become void.


1. Part Identification

- 1 Lift Handle
- 2 Upper Platen (Heater)
- 3 Lower Platen
- 4 Control Panel
- 5 Pressure Knob
- 6 Power Switch



1.1 Control Panel

- 1 Temperature
- 2 Time
- 3 Number of uses
- 4 Set Parameter
- 5 Adjust Value
- 6 Reset the counter



Heat Platen Size	23 X 30 cm
Power	900 W MAX ± 5%
Voltage	220 V / 110 V 50~60 Hz
Temp. Range	0-220 °C (32-482 °F)
Time Range	0-999 seconds

2. Initial Setup

General Guidelines:

- 1. To avoid burns, do not touch the heated platen during operation.
- 2. Keep hands clear of the upper platen of the press during lock down as the pressure may cause injury.
- 3. Press should be placed on a sturdy, suitable stand at least 92 cm L x 61 cm W x 74 cm H.
- 4. Work area must be kept clean, tidy and free of obstructions.

Please avoid the following:

- 1. Failure to comply with the instructions relative to installation, use and maintenance as described in this manual.
- 2. System or environmental conditions not suitable for proper machine operation.
- 3. Unauthorized alterations to the machine.
- 4. Operation by unqualified and untrained personnel.

CAUTION! Failure to follow these instructions will cause:

- 1. Erratic controller functions.
- 2. Inaccurate displays and slow heat-up.
- 3. The circuit breaker to possibly disengage.


3. Adjusting temperature, time and pressure

Adjusting time and temperature



1. Turn on the machine, press "SET" button to enter temperature setting mode first;

↓ Temp. Setting Interface




2. Press "↓" and "↑" buttons to adjust the value;



3. Press "SET" button again to enter time setting mode;

↓ Time Setting Interface



4. Press "↓" and "↑" buttons to adjust the value;



5. Last, press "SET" button again to save the settings and exit setting mode.


Notes

- No matter which interface is shown, if the pressure handle is pressed down, the machine will start countdown automatically. You can lift it up to stop the countdown.
- No matter which interface is shown, if you press "CLEAR" button, the machine will start countdown automatically. You can press "CLEAR" button again to stop the countdown.


How to switch between °C and °F?

- 


- Long press "SET" button for 5 seconds to enter temp. unit switching mode;
 - Press "↓" and "↑" buttons to switch between °C and °F;
 - Long press "SET" button for 5 seconds again to save the setting.



As shown above, the current temperature unit is °C.



As shown above, the current temperature unit is °F.

Adjusting the pressure

With the lift handle in the **DOWN** position, rotate the pressure adjustment knob.

- Rotate clockwise to increase pressure
- Rotate counter-clockwise to decrease pressure
- Remember to allow for the thickness of your garment when adjusting pressure.

WARNING: Structural damage caused by excessive pressure is NOT covered under the limited warranty.



4. Applying with your press



1 Turn on the heat press;



2 Adjust the pressure by rotating the knob;



3 Set the desired temperature and time;




4 Place your artwork on the garment;



5 Cover the garment with parchment paper;



6 Press down the handle and the machine will start the countdown automatically;



7 After the countdown, the machine will beep a sound. Lift up the handle;



8 Enjoy your new creation!

5. Terms of Guarantee

5.1 Warranty policy



SISER S.r.l. guarantees its **SISER CRAFT PRESS GO!** machine for a period of 24 months from the date of shipment.

During the warranty period, any defective or broken parts will be repaired or replaced free of charge by **SISER S.r.l.** on its premises in Vicenza.

Any defective parts replaced must be returned to Siser S.r.l. after replacement. The purchaser assumes all transport or delivery charges of the spare parts.

All consumables and materials used for routine maintenance are excluded from the warranty, as well as any parts damaged due to improper use of the machine.

Repairs and/or replacements made during the warranty period do not extend the warranty.

5.3 CE Certification - reference standards

The **SISER CRAFT PRESS GO!** machine is equipped with electrical parts operating at a voltage ranging between 50 V and 1000 V alternating current, and is subject to the Low Voltage Directive 2014/35/EU and the Electromagnetic Compatibility Directive 2014/30/EU.

Users must remember that in addition to following the instructions in this manual, the legislation on the subject of safety within your country must also be adhered to.

5.2 Liability



The only configurations and uses allowed by the manufacturer are those expressly described in the manual.

SISER S.r.l. assumes no liability for:


- failure to comply with the instructions relative to installation, use and maintenance as described in this manual;
- system and environmental conditions that are not conducive for the machine to perform;
- unauthorized alterations to the machine;
- operation by unqualified and untrained personnel

6. Retiring the machine, demolition and disposal

If the machine has to be demolished, it must be separated into similar parts, which must be separately disposed of in accordance with legislation in force. The replaced parts must not be disposed of in the environment, but disposed of according to legislation in force in the location of machine use.

The basic components of the machine parts are steel, stone wool, aluminium and plastic.

The symbol:



depicted on the machine means the waste is subject to "separate collection". Therefore, the user must take (or have taken) the waste material to a waste sorting facility run by local municipalities, or return it to the retailer on purchase of a new, equivalent machine.

In Italy, illegal disposal of the product by the user is subject to a fine pursuant to Art. 255 and thereafter of Legislative Decree no. 152/06.

Information for the users

Separate collection of this machine at the end of its life is organized and managed by the manufacturer. The user who wishes to dispose of this equipment should therefore contact the manufacturer and follow the instructions adopted by the latter to ensure separate collection of the machine at the end of its life.

Correct separate collection for recycling, treatment and environmentally compatible disposal of waste material contributes to the prevention of possible negative effects on health and the environment, and facilitates the reuse and/or recycling of the materials of which it is composed.

Improper disposal of the product by the owner is a punishable violation of the regulations in force.

NOTES

PERFECT FOR APPLYING DESIGNS TO:



T-Shirts



Onesies



Tote bags



Coasters



Kitchen aprons



Mousepads



SISER CRAFT PRESS GO!

OPERATOR'S MANUAL

Certification Number: GMA-529926

SISER S.r.l.

Viale della Tecnica, 18
36100 VICENZA, ITALY
tel. +39 0444 287960
fax +39 0444 287959

info@siser.it - www.siser.com

