

Use & care manual

MINI SCALP MASSAGER

SL-49A1



 **SNAILAX®**

Safety Instructions



READ ALL INSTRUCTIONS BEFORE USE.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

- ALWAYS unplug the appliance from the electrical outlet immediately after using and before cleaning.
- This item is NOT A TOY. Close supervision is necessary when this appliance is used by, on, or near children or disabled persons.
- NEVER leave an appliance unattended when plugged in.
- NEVER insert pins or other metallic fasteners into the appliance.
- Use this appliance for the intended use as described in this booklet. DO NOT use attachments not provided by SNAILAX.
- NEVER operate the appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged.
- Keep cable away from heated surfaces.
- Excessive use could lead to the product's excessive heating and shorter life. Should this occur, discontinue use and allow the unit to cool before operating.
- NEVER drop or insert any object into any opening.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- DO NOT attempt to repair the appliance. All servicing of this appliance must be performed by authorised SNAILAX service personnel only.
- Do not place or store appliance where it can fall or be pulled into a bath or sink. Do not place in or drop into water or other liquid.
- Do not use this product for medical treatment.

Safety Instructions

If you suffer from any of the medical conditions listed below, consult with a doctor before using this relaxation massage device.

If you:

suffer from a heart condition
have a sensory disorder or pacemaker
suffer from osteoporosis or diabetes
have a malignant tumor
have neurological disorder or perceptual disorder on head
have fractured or head surgery of your massaging area
head skin disease and allergic dermatitis.
suffering from acute diseases or are undergoing medical treatment
we advise you to consult with your doctor before using this massager.

- Failure to follow the above may result in the risk of injury.

Troubleshooting

Trouble	Reason/Solution
Can not start the massager	Battery Low/ Please charge it before using
The massager stoped abnormally	Battery runs out of power/ charge the battery Self-timed 10 mins is out/ restart the product
Massager slight noise	It is normal working noise of the internal mechanism

Instruction

1. Built-in Lithium battery
2. One control button
3. 10 minutes timer
4. Automatically protect function
5. 3 massage modes
6. Charging cable
7. IPX7 waterproof
8. 3D head massage

Contents

- Mini Smart Scalp Massager
- Charging cable
- Interchangeable massage heads
- Lanyard



Technical data

Model:	SL-49A1
Product Input:	DC5V 1.0A
Rated Power:	5W
Automatic runtime:	10 minutes

Instructions for use

Please Make sure to relax before using this machine,
Hold the device and put the massage heads onto scalp
to massage.

Assemble your desired massage heads.



Four leaf grass shape
massage head

Use to wash your
face



Lotus shape massage
heads

Use to massage your
head and other
body part

Extend the handle by adding the lanyard to better hold
the massager and enjoy massage.



Instructions for use



LONG PRESS -----Switch on and off

SHORT PRESS-----Switch massage speed

The speed is:

SOFT → STRONG → COMBINATION

Initial speed is strong, cycle switching

- ✱ LED indicator flashes once when switching to Soft mode
- ✱✱ LED indicator flashes twice when switching to Strong mode
- ✱✱✱ LED indicator flashes three times when switching to Combination mode

Battery Charging

Connect the USB cable to any USB charger, it can be plugged in the portable power bank, mobile phone battery chargers, laptop and any USB port.



- ❗ Before charging, ensure that the charging port, charging terminal, charging line and product shell are dry.
- ❗ The product will be in sleep mode when charging.

Battery Charging

- ⚡⚡⚡⚡ The light flashes quickly when battery is low
- ⚡-⚡-⚡- When charging, the light flashes slowly
- ⚡—— When fully charged, LED lights up all the time

1. Normally it takes about 2 hours to fully charge.
2. The machine does not work when charging.

Notes and Maintenance

Notes

1. It is waterproof device, you can use cleaning fluid and water to clean it (do not sink it into water for a very long time).
2. Please use dampcloth or neutral detergent to clean the product and wipe dry afterwards.
3. Do not use sharp brush, sharp tool, gasoline and diesel to clean it.

Maintenance

1. Please keep it into a box and keep in a safe, dry and cool place.
2. Do not keep it in any place with high temperature, near fire or direct sunlight, or it may faded or damaged
3. Do not contact benzene, dilient or any other corrosive liquid.

Warranty

If you have any issue about the product, please feel free to contact us by sending email to support@snailax.com. We will strive to provide the best service possible within 24 hours.

30 days unconditionally Return

Snailax product can be returned to receive a full refund for any reason within 30 days. Please contact our customers service (support@snailax.com), our staff will contact you within 24 hours.

90 days refund/replace

Snailax product can be returned / replaced within 90 days if the product break down in the period of proper use.

12 months Warranty

If the product break down within 12 months in the period of proper use, customers can enjoy the relevant warranty to get them replaced.

Attention!

No warranty will be given to any force majeure and man-made causes to a defective product, such as improper care, personal tear down and willful damage, etc.

Warranty

Extend Warranty for Free

1) Enter the following URL or scan the QR code below to find Snailax facebook page and like it, enter "Warranty" to messenger to extend your warranty from 1 year to 3 years.



<https://www.facebook.com/snailax>

OR 2) Send message "Warranty" and email us support@snailax.com to extend your warranty from 1 year to 3 years.

Have question ?

Tel: 734-709-6982

Monday-Friday 9:00AM-4:30PM

Email: support@snailax.com

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



2750 Carpenter Road,
Suite 1 B, Ann Arbor, 48108
Tel: 734-709-6982
support@snailax.com
www.snailax.com