




 Quick Guide V1.1  Matter Over WiFi Smart Plug S41STPB	Power on  When the device is used for the first time, it will enter pairing mode by default after being powered on. At this time, the Wi-Fi LED indicator will flash in a pattern of "two short and one long." 1	① The device will exit the Pairing Mode if not paired within 10mins. If you want to enter this mode, please long press button for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release. 2	Matter user guide  Add to Apple via Matter  Add to Google via Matter  Add to Alexa via Matter  Add to SmartThings via Matter Open the Matter-compatible App and scan the Matter QR code on the device to add it. 3	eWeLink user guide 1. Download the eWeLink App   2. Add Device Open the eWeLink App and scan the QR code on the device, then follow the instructions given by the app to proceed. 4
---	---	---	--	---

 ① If the page doesn't display after scanning the code, please click the '+' button in the top right corner of the eWeLink App homepage and select 'Add Device' to proceed. 5	User Manual https://sonoff.tech/usermanuals Enter the website provided above to view the User Manual for the device. Rating: 120V~ 50/60Hz 15A Max μ general use Max load: 1800W Operating temperature: 10T40 (-10°C~40°C) 6	FCC compliance statement Responsible Party Name: SONOFF TECHNOLOGY LLC Address: 14777 NE 40th St, Suite 201 Bellevue, WA 98007 Email Address: usres@itead.cc FCC ID: 2APN5-S41STPB 1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This 7	equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with 8	minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Sonoff Manufacturer: Shenzhen Sonoff Technologies Co., Ltd. Address: 3F & 6F, Bldg A, No. 663, Bulong Rd, Shenzhen, Guangdong, 518000, China Website: sonoff.tech Service email: support@itead.cc MADE IN CHINA  Intertek 5012520 CONFORMS TO UL STD.60730-1 CERTIFIED TO CAN/CSA STD.E60730-1 9
--	---	---	---	--