






Setup Guide Manuel de configuration 設定指南




Setup Guide / セットアップガイド / 安裝指南 / دليل الإعداد / 설치 가이드 / Guía de configuración / Guide d'installation / Installatiehandleiding / Einrichtungshandbuch / Guia de configuração / Guida di installazione / Startguide / Installationsvejledning / Asetusopas / Innstillingsveiledning / Przewodnik ustawień / Průvodce nastavením / Sprievodca nastavením / Beállítási útmutató / Ghid de configurare / Ръководство за настройка / Οδηγός εγκατάστασης / Seadistusjuhend / Uzsākšanas ceļvedis / Nustatymo vadovas / Priročnik za pripravo / Vodič za postavljanje / Vodič za podešavanje / מודריך הגדרה




1




2






3



4



5



https://rd1.sony.net/help/tv/27q102/h_zz/