


External SSD/Lecteur SSD externe/External SSD externa/Εξωτερική SSD/Зewnętrzny dysk SSD/SSD extern/Işorinis SSD/Внешний SSD/Сырткы SSD/外接固態硬碟



Operating Instructions/Mode d'emploi/Bedienungsanleitung/Manual de instrucciones/Istruzioni per l'uso/Manual de instruções/Gebrauchsanwijzing/Instrukcja obsługi/Návod k obsluze/Használati útmutató/Návod na obsluhu/Οδηγίες λειτουργίας/Kasutusjuhend/Εκπλοατίας instructions/Lietišanas instrukcijas/Bruksanvisning/Navodila za uporabo/Bruksanvisning/Betjeningsvejledning/Käyttöohjeet/Instrucțiuni de utilizare/Инструкции за експлоатация/Уpute за rad/Упутstvo za upotrebu/Упатство заупотреба/Удһәҙимәт ғәҙәримоти/Инструкция по эксплуатации/Пайдлаулан нұсқаулығы/使用説明書/사용설명서/تعليمات التشغيل/Kullanma kılavuzu

SL-EG2, SL-EG5, SL-E1

© 2018 Sony CorporationPrinted in Thailand/Печатно в Тайланде/Тайландда басып шығарылған/Надруковано у Тайлңди



A



B

English Data recording device

WARNING
Keep away from children. If swallowed, promptly see a doctor.
To reduce fire or shock hazard, do not expose the unit to rain or moisture.
To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

For Customers in Europe
This product has been manufactured by or on behalf of Sony Corporation.
EU Importer: Sony Europe Limited.
Inquiries to the EU Importer or to the product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe Limited, Da Vincielaan 7-D1, 1935 Zaventem, Belgium.
Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)
This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste disposal. For more detailed information about recycling of this product, please contact your local Civil Office, your household waste disposal service or the shop where you purchased the product.

For the customers in the U.S.A.
NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.
(POUR LES CONSOMMATEURS AUX ÉTATS-UNIS, NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC)
For questions regarding your product or for the Sony Service Center nearest you, Sony Electronics Inc., Media Services, 11302 Eastpoint Drive Building B, Suite 600, Laredo, TX 78045; mediaservices@am.sony.com or (877) 440-3453.
The number below is for the FCC related matters only.

Regulatory Information
Declaration of Conformity
Trade Name: SONY
Model No.: SL-EG2, SL-EG5, SL-E1
Responsible Party: Sony Electronics Inc.
Address: 16355 Via Espirito, San Diego, CA 92127 U.S.A.
858-942-2230
This device complies with Part15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION
You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.
Notes:
• This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, you can be determined by turning the equipment off or on. If the use of the equipment is found to be the cause of the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
• The telephone number shown above pertains to the declaration of conformity, not the contact for our customer support. Contact information for customer support on the warranty card.

For the Customers in Canada
CAN ICES-3(B)/NMB-3(B)
Read this first
See illustration **B16** for the connection method.

Basic Operation
Be careful when handling the device after extended periods of use as the surface may be hot.
If the device is not recognized by the PC or host device you are using, remove the device, shutdown or restart your PC or host device, and try plugging the device again.
Installing:
Plug the device into the USB port on your PC, smartphone or Tablet.
Please remove the device properly according to the proper procedure depending on the OS.
Otherwise, data may not be recorded correctly.
LED Indicator:
When the data transfer is in progress, the indicator light is flashing. Please do not remove the device while flashing.
It is strongly recommended that you periodically back up the data written on the

Sony Corporation assumes no liability for any damage or loss of data which may occur.

Notes on Use
This unit is a Precision Instrument. Saved data may be lost due to sudden failure. As a precaution against possible failure, periodically save the data in this unit. Otherwise, Sony will not repair, restore or replicate recorded contents under any circumstances. Furthermore, Sony shall not be responsible for any damage to or loss of recorded data for any cause.
• Note the following when using other USB devices while connecting this unit to equipment.
— The transfer speed of this unit may become slow.
— You may be unable to use this unit if it is connected to equipment via a USB hub. If this happens, reconnect this unit directly to the USB port of the equipment.
• Do not connect a wrong USB cable to this unit, which may damage the socket.
• Do not remove this unit from the equipment while writing, reading or deleting data. Do not strike, bend, drop, wet, or apply excessive force to this unit. Doing so may damage the data.
• If this unit is still connected to the PC in the following situations, the PC may not operate correctly.
— When you start or restart the PC.
— When the PC enters sleep or hibernation, or returns from either.
Disconnect this unit from the PC before doing these operations.
Capacity is based on 1 GB = 1 billion bytes. A portion of the memory is used for data management functions and therefore usable storage capacity will be less.

Français Enregistreur de données
AVERTISSEMENT
Tenir hors de portée des enfants. En cas d'ingestion, consulter immédiatement un médecin.
Alors que les risques d'incendie ou de décharge électrique, n'exposez pas cet appareil à la pluie ou à l'humidité.
Pour éviter toute électrocution, ne pas ouvrir le boîtier. Confier l'entretien à un technicien qualifié uniquement.
For the clients in Europe
Ce produit a été fabriqué par ou pour le compte de Sony Corporation.
Importateur dans l'UE: Sony Europe Limited.
Les questions basées sur la législation européenne pour l'importateur ou relatives à la conformité des produits doivent être adressées au mandataire: Sony Belgium, bijkantoor van Sony Europe Limited, Da Vincielaan 7-D1, 1935 Zaventem, Belgique.
Traitement des appareils électriques et électroniques finis de la vie utile (

