


FLOWTIP MILK JUG®


subminimal®



HEAT RESISTANT
SILICONE SLEEVE
/ ERGONOMIC HANDLE

NEW ROUND SPOUT

SMOOTH NECK



FLOWTIP HANDLESS

A handleless jug design featuring a silicon sleeve that offers maximum control, perfect for the purist with a passion for control.

Capacity	450 ml / 15 oz
Dimensions	110 × 82 × 82 mm
Weight	240 g
Handle Material	Silicone
Patented	Yes

FLOWTIP BLACK

A black coated beauty with a heat-resistant handle for pouring incredible latte art.

Capacity	450 ml / 15 oz
Dimensions	110 × 82 × 120 mm
Weight	250 g
Handle Material	Phenolic Resin
Patented	Yes

PERFECT YOUR LATTE ART

FLOWTIP VS TRADITIONAL JUG

The FlowTip Jug is designed with a sharp tip, a precise tangent, and a smooth neck for better control. Its ergonomic shape and heat-resistant build make it safer and easier to use, while traditional milk jugs lack these key features.

HOW TO USE

Gas Stovetop:

Use the lowest setting to prevent direct flame contact with the handle.

Electric Stovetop:

Position the jug slightly off-center to avoid overheating the handle. Be cautious, as abrasive stovetops may scratch the jug.


Induction Stovetop:

Requires an induction diffuser for compatibility.

Note: Do not heat a second batch without cleaning the jug to prevent burning. Always heat milk on the lowest setting (approx. 2 min) to reach 55–65°C.

CLEANING

- Rinse or soak the jug immediately after use for easy cleaning.
- Use a cleaning brush for stubborn milk residue, milk jug cleaners, or soak in a baking soda and lemon juice mixture.



COMPATIBILITY

- Works with gas and electric stovetops.
- Induction stoves require an induction diffuser.
- Not microwave safe.

HANDLING THE RUBBER SLEEVE

Ensure the rubber sleeve is properly positioned by pushing it down slightly at the base to match the jug's shape.

This prevents slipping and ensures safer handling.

PACKAGE CONTENTS

- One Black Coated / Handleless / White Handleless FlowTip Jug
- One Certificate of Authenticity
- Access code for Latte Art Master Class

NEED HELP?

subminimal.com/pages/help

Subminimal Pte. Ltd.
14 Robinson Road 08-01A
Singapore, 048545
www.subminimal.com
hello@subminimal.com

FLOWTIP[®]

FLOWTIP MILK JUG

subminimal[®]

SUBMINIMAL.COM

SAFETY INSTRUCTIONS WARNING: READ BEFORE USE



STOVETOP USE

Safe for gas & electric stoves.
Not induction compatible.



PRECAUTIONS

Keep gas flame under the base. Do not let flame touch the handle.



TEMPERATURE

Do not heat above 65°C (150°F).

MORE

Additional details & user manuals visit subminimal.com/help

HQ: SUBMINIMAL PTE. LTD,
14 Robinson Road #08-01A,
048545 Singapore
hello@subminimal.com

RP: Obelis s.a. - Bd. Général Wahis,
53, 1030 Brussels, Belgium
mail@obelis.net

AVERTISSEMENT

Lire avant utilisation.

UTILISATION SUR PLAQUE

Compatible avec plaques à gaz et électriques.
Non compatible induction.

PRÉCAUTIONS

Maintenir la flamme sous la base.
Ne laissez pas la flamme toucher le manche.

TEMPÉRATURE

Ne pas chauffer au-delà de 65°C (150°F).

FR

WARNUNG

Vor Gebrauch lesen.

VERWENDUNG AUF DEM HERD

Geeignet für Gas- und Elektroherde.
Nicht induktionsgeeignet.

VORSICHTSMAßNAHMEN

Gasflamme unter der Basis halten.
Flamme darf den Griff nicht berühren.

TEMPERATUR

Nicht über 65°C (150°F) erhitzen.

DE

ADVERTENCIA

Leer antes de usar.

USO EN COCINA

Apto para cocinas de gas y eléctricas.
No compatible con inducción.

PRECAUCIONES

Mantenga la llama de gas bajo la base.
No permita que la llama toque el mango.

TEMPERATURA

No calentar por encima de 65°C (150°F).

ES

AVVERTENZA

Leggere prima dell'uso.

USO SU PIANO COTTURA

Adatto a fornelli a gas ed elettrici.
Non compatibile con induzione.

PRECAUZIONI

Mantenere la fiamma sotto la base.
Non lasciare che la fiamma tocchi il manico.

TEMPERATURA

Non riscaldare oltre i 65°C (150°F).

IT

WAARSCHUWING

Lees vóór gebruik.

GEBRUIK OP KOOKPLAAT

Geschikt voor gas- en elektrische kookplaten.
Niet geschikt voor inductie.

VOORZORGSMAATREGELEN

Houd de gasvlam onder de basis.
Laat de vlam het handvat niet raken.

TEMPERATUUR

Niet verhitten boven 65°C (150°F).

NL

VARNING

Läs före användning.

ANVÄNDNING PÅ SPIS

Säker för gas- och elspisar.
Ej kompatibel med induktion.

FÖRSIKTIGHETSÅTGÄRDER

Håll gaslågan under basen.
Låt inte lågan nudda handtaget.

TEMPERATUR

Värm inte över 65°C (150°F).

SE

警告

使用前请阅读。

炉灶使用

适用于燃气灶和电炉。
不兼容电磁炉。

注意事项

保持火焰在底部下方。
不要让火焰接触手柄。

温度

加热温度不得超过 65°C (150°F)。

CN

경고

사용 전에 읽어 주세요.

가열기 사용

가스 및 전기레인지 사용 가능.
인덕션에는 호환되지 않습니다.

주의사항

불꽃은 반드시 바닥 아래에 유지하세요.
불꽃이 손잡이에 닿지 않도록 하세요.

온도

65°C (150°F) 이상으로 가열하지 마세요.

KR