



ThermoWorks

ThermaPod Logger



Operating Instructions

ON/OFF

Press any button to turn on the instrument. The date and time will flash across the screen before showing the current temperature.

The instrument will automatically power off after 30 seconds.

SETTING UP THE LOGGER

Press and hold SET for 3 seconds to enter the setting mode. Set the Month, Day, Year, Time (Hours and Minutes), Samples Interval, Record On/Off, and F to C. To adjust these settings, press the '▷' button to change the value, and press SET to save and move to next. While in settings mode, press both buttons to reset the value to the default settings.

START LOGGER

Press both buttons to start the Logger. **Please note:** This will erase any previous readings in the memory, so ensure that all readings are downloaded before restarting.

LED INDICATION

The green LED will flash at each sample interval when logging. The red LED will show when instrument is connected to PC.

READING THE LOGGER

If the instrument shows 'DAtA', data needs to be downloaded. Plug the instrument into a PC. When connected to a PC, 'FILE USB' will show on the display. A PDF log summary will automatically pop up as a Mass Storage Device.

WARNING - Do not expose the thermometer to temperatures over 185°F (85°C) or use in ovens, this will result in incorrect readings or damage to the instrument.

ERROR MESSAGE

If the thermometer has developed a fault the instrument will show 'LLL'. If the display shows 'LLL' the reading is outside of the lowest measurement range value -13°F (-25°C). If the display shows 'HHH' the reading is outside of the highest measurement range value 185°F (85°C) – Please contact Tech Support for assistance.

BATTERY REPLACEMENT

The battery will need to be replaced when the instrument displays 'bAt'. Replace the battery with a 3 volt lithium coin cell (CR2032), making sure the polarities are correct, close and tighten up the battery cover. **Please note:** Ensure the battery cover is fully tightened after battery replacement as this may affect the water resistant function.

BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

GUARANTEE

ThermaPod carries a two-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ThermoWorks, be either repaired or replaced without charge. This warranty does not apply to probes, where a six-month period is offered. Full details of liability are available within ThermoWorks' Terms & Conditions of Sale at www.thermoworks.com/product-warranty.

 WARNING	
• INGESTION HAZARD: This product contains a button cell or coin battery • DEATH or serious injury can occur if ingested. • A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. • KEEP new and used batteries OUT OF REACH OF CHILDREN. • Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.	

For warranty, service, and technical assistance, please contact ThermoWorks' Technical Support at (385) 330-0591 or email at techsupport@thermoworks.com.

Copyright by ThermoWorks, Inc. Content may not be used in whole or in part, without written consent.

ThermoWorks, the ThermoWorks logo and ThermaPod are registered trademarks of ThermoWorks, Inc. All Rights Reserved.



ThermoWorks

ThermoWorks, Inc.
Utah, U.S.A.

Ph: 801-756-7705 Fax: 801-756-8948
www.thermoworks.com

