



Quick Start Guide

WH22FA9420 | WH24FA9420 | WH27FA9420




ASSEMBLY / MONTAJE / ASSEMBLAGE

What's included:

A - HDMI Cable (22"/24"/27")

B - Base/Stand (22"/24"/27")

C - Adapter (22"/24"/27")




For customer support,
scan the QR code.
Para atención al cliente,
escanee el código QR.
Pour le support client,
scannez le code QR.

Tools you will need:



1. Connecting to your PC.



HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.


Questions? Call (800) 701-0680 or
visit westinghouse.com/support

¿Tiene preguntas? Llame al (800) 701-0680 o visite westinghouse.com/support
Des questions? Téléphoner au (800) 701-0680 ou visitez westinghouse.com/support

ASSEMBLY / MONTAJE / ASSEMBLAGE


2. Installation of base

Take out the bracket and base first, and then open the upper cover.




Base installation steps:

- ① Insert the support into the base;
- ② Fasten the stand into the rear shell in the direction of the arrow.



When it is necessary to disassemble the whole base, do the following steps ;

- ① Press down on the stand switch;
- ② Take the base out in the direction of the arrow



Simply hold the stand with hand to stand the monitor upright.

⚠ Note: During standing of the whole monitor, do not press the liquid crystal screen with hand to avoid damage to the screen.

