



Quick Start Guide

WC24RX6230 | WC24RX6230W



For customer support,
scan the QR code.
Para atención al cliente,
escanee el código QR.
Pour le support client,
scannez le code QR.





Tools you will need:




ASSEMBLY / MONTAJE / ASSEMBLAGE

What's included:

- A - DP Cable
- B - Base/Stand
- C - Adapter
- D - Screws



1. Connecting to your PC.



HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.


Questions? Call (800) 701-0680 or
visit westinghouse.com/support

¿Tiene preguntas? Llame al (800) 701-0680 o visite westinghouse.com/support
Des questions? Téléphonez au (800) 701-0680 ou visitez westinghouse.com/support

ASSEMBLY / MONTAJE / ASSEMBLAGE

2. Installation of base


Remove the upper foam cover and put it aside, take out the monitor film bag and put the monitor in the lower foam cover.



Base installation steps:

Take out the base, insert the base into the stand, and lock one M4×6mm, H=12.5mm hand screw.

Note: Going through aforesaid steps adversBase



Simply hold the stand with hand to stand the monitor upright.

⚠ Note: During standing of the whole monitor, do not press the liquid crystalscreen with hand to avoid damage to the screen.

