



Quick Start Guide



For customer support,
scan the QR code.
Para atención al cliente,
escanee el código QR.
Pour le support client,
scannez le code QR.

Tools you will need:







WC27RX6250 | WC27RX6250W | WC27RX6250R | WC27RX6250G | WC27RX6250P | WC27RX6250C | WC27RX6250B
WC32RX6250 | WC32RX6250W | WC32RX6250R | WC32RX6250G | WC32RX6250P | WC32RX6250C | WC32RX6250B


ASSEMBLY / MONTAJE / ASSEMBLAGE

What's included:

- A - DP Cable
- B - Base/Stand
- C - Adapter
- D - Screws



1. Connecting to your PC.



HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



Questions? Call (800) 701-0680 or
visit westinghouse.com/support

¿Tiene preguntas? Llame al (800) 701-0680 o visite westinghouse.com/support
Des questions? Téléphoner au (800) 701-0680 ou visitez westinghouse.com/support

ASSEMBLY / MONTAJE / ASSEMBLAGE

2. Installation of base


Remove the upper foam cover and put it aside, take out the monitor film bag and put the monitor in the lower foam cover.



Base installation steps:

Take out the base, insert the base into the stand, and lock one M6×14mm, D=10mm hand screw.

Note: Going through aforesaid steps adwersBase



Simply hold the stand with hand to stand the monitor upright.

⚠Note: During standing of the whole monitor, do not press the liquid crystalscreen with hand to avoid damage to the screen.

