



Quick Start Guide

WM24FA9420 | WM27FA9420



For customer support,
scan the QR code.
Para atención al cliente,
escanee el código QR.
Pour le support client,
scannez le code QR.

Tools you will need:



ASSEMBLY / MONTAJE / ASSEMBLAGE





What's included:

A - DP Cable (24"/27")


B - Base/Stand (24"/27")

C - Adapter (24"/27")

D - Screws (24"/27")



1. Connecting to your PC.



HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.


Questions? Call (800) 701-0680 or
visit westinghouse.com/support

¿Tiene preguntas? Llame al (800) 701-0680 o visite westinghouse.com/support
Des questions? Téléphonez au (800) 701-0680 ou visitez westinghouse.com/support

ASSEMBLY / MONTAJE / ASSEMBLAGE


2. Installation of base

Remove the upper foam cover and put it aside, take out the monitor film bag and put the monitor in the lower foam cover.




Base installation steps:

- ① Insert the base into the support and lock attached 2M4*8 screws;
- ② Tilt the base in the direction of the arrow into the back of the shell holes rotate the whole base clockwise downward and install it.



When it is necessary to disassemble the whole base, do the following steps ;

- ① Push up the slider near the VESA cover of the base;
- ② Rotate the entire base counterclockwise upwards;
- ③ Tilt the base in the direction of the arrow and take it out.



Simply hold the stand with hand to stand the monitor upright.

⚠ Note: During standing of the whole monitor, do not press the liquid crystal screen with hand to avoid damage to the screen.

