



Quick Start Guide

WC49BX6230



For customer support,
scan the QR code.
Para atención al cliente,
escanee el código QR.
Pour le support client,
scannez le code QR.

Tools you will need:



ASSEMBLY / MONTAJE / ASSEMBLAGE

What's included:






A - DP Signal Cable

B - Base/Stand


C - Power Cord

D - Wall Mounting Adapter

E - Screws



1. Connecting to your PC.



HDMI[®]
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.


Questions? Call (800) 701-0680 or
visit westinghouse.com/support

¿Tiene preguntas? Llame al (800) 701-0680 o visite westinghouse.com/support
Des questions? Téléphonez au (800) 701-0680 ou visitez westinghouse.com/support

ASSEMBLY / MONTAJE / ASSEMBLAGE


2. Installation of base

Open the package to take out foams and put them on a flat tabletop. Remove the extra parts and the foam covering the monitor, take out the monitor film bag and put the monitor in the lower foam cover.




Base installation steps:

- ① Insert the base into the support and lock attached 3 screws;
- ② Align the stand stem's bracket with the opening on the back of the monitor, and carefully insert bracket, fit the stand assembly and display together.



When it is necessary to disassemble the whole base, do the following steps ;

- ① take off the decorative cover of the back shell
- ② pull down the quick remove button to remove the base.



Simply hold the stand with hand to stand the monitor upright.

⚠ Note: During standing of the whole monitor, do not press the liquid crystal screen with hand to avoid damage to the screen.

