

Features



Convertible Cup Holders



Adjustable Side Walls



11 lbs (5 kg)

Note: Do not exceed the weight limits:

Assembling the Flex Snack Tray



Ensure the tray is laid flat and smooth.



Lift the side walls and fasten them securely using the velcro straps.




Fold the cup holders inward and fasten them using the magnetic flaps.

Attaching the Flex Snack Tray



Confirm that the pocket flap is positioned over the folding hinge.



Position the snack tray in the center of the stroller wagon and attach the hooks securely onto the frame.



Follow Us!



WonderFold.com

Questions? Email Us: hello@wonderfold.com

Adjusting the Cup Holders



Lift the cup holder flap upward and outward over the frame.



Guide the cup holder mesh downward through the opening.



Secure the magnetic side flaps to the side walls of the cup holders.

Expanding the Table Top



Extend the cup holders as instructed in the previous step.




Unfasten the Velcro straps to release the side walls.




Lower the side walls by folding them down.


Folding the Flex Snack Tray



Unfasten the magnetic flaps and extend the cup holders.



Undo the Velcro straps and fold the side walls downward.



Once fully flattened, fold the cup holders inward, then press down on the cup holder mesh. The tray is now ready for storage.



Follow Us!



WonderFold.com

Questions? Email Us: hello@wonderfold.com