

# Parent Console

## Features & Instructions

### Features



Insulated  
Cup Holders



Covered Storage  
Compartment



Removable  
Hand Clutch



Wet Wipe  
Compartment



Front Mesh  
Pockets



Hanging Hooks



Zippered  
Back Pocket



Removable & Adjustable  
Shoulder Strap



Reusable Wet  
Wipe Pouch

**Note:** Do not exceed the weight limit of 6.6 lbs (3 kg)

### Attaching the Hooks



Face the back of the hook  
towards the back of the console.



Using your thumbs to spread the  
hook clip open wide enough to  
clip on to the console's buckle.



Attachment complete.

### Attaching the Shoulder Strap



Press the shoulder strap clip onto  
the hanging hook buckle on the  
side facing out away from the  
parent console.



Installation Complete.  
To remove the shoulder strap  
press the clip open and slide it off  
the buckle.

# Parent Console

## Features & Instructions

### Attaching the Parent Console

#### Handlebar Straps



If your stroller wagon has an adjustable handlebar, adjust it to a 90° angle to the wagon frame.



Wrap one of the velcro straps, with the velcro side facing out, around the base of the handlebar, then loop through the buckle to secure the strap. Repeat for the other velcro strap.



Once the parent console is securely attached, you may adjust the handlebar height to your desired level.

#### Hanging Hooks



Make sure that there is a clear space on the frame where the hooks will be placed on.



Place hooks onto the frame and firmly press down until hooks are securely in place.



Installation Complete

**Note:** Hooks should not be placed on top of seat or accessory clamps already on the frame.

### Inserting the Reusable Wet Wipe Pouch



Unzip the wet wipe compartment and insert the wet wipe pouch.



Guide the pouch's wipe dispenser through the compartment opening until the dispenser is completely out.