

ProFlex

Portable Fan



Say hello to your new ProFlex Portable Fan!
Please take a moment to read through this user manual and keep it handy for future reference.

Specifications:

Power: 5W
Voltage: 5V 1A
Battery: 2400mAh
Charging time: 3 ~ 4h
3 speeds: Low, Medium, High
Product size: 13.98 x 6.69 x 2.6 inch
(35.5 x 17 x 6.6 cm)

Estimated Working Time

High speed: 3 hours
Medium speed: 5 hours
Low speed: 9 hours

WONDERFOLD®

Questions?

hello@wonderfold.com



www.wonderfold.com

WONDERFOLD®

ProFlex


Portable Fan



User Manual

www.wonderfold.com

How to Assemble



How to Use

Be sure to charge your ProFlex Portable Fan before using for the first time.

To turn on:


Press the fan button located on the back.

To change fan speed:

Press the fan button again to cycle through the different speeds.

To turn off:

Press the fan button one more time.



How to Charge

The ProFlex Portable Fan can operate on battery power. You'll see a white light when the ProFlex Portable Fan is running.



To charge your ProFlex Portable Fan, connect the provided Micro-USB cable to a USB power source. You can continue using your ProFlex Portable Fan while charging.

The LED charging light indicator will glow red while the fan is charging. Once it's fully charged, the indicator light will turn off.

