




WONDERFOLD®

XR Series

Recline Stroller Wagons



www.wonderfold.com



X2R

 2 Seater

X4R

 4 Seater

WONDERFOLD®

Assembly & Safety Instructions



WARNING

X2R - Never exceed the maximum seat limit of 2 children.

X4R - Never exceed the maximum seat limit of 4 children.

- Ensure the harness is correctly fitted to your child. Adjust the shoulder strap according to your child's size.
- The product may become unstable if the manufacturer's recommended load is exceeded:
 - X2R** - Product maximum weight limit: 150 lbs. (68 kg).
 - X4R** - Product maximum weight limit: 180 lbs. (81.6 kg).
- DO NOT place more than 1.1 lbs. (0.5 kg) in each storage pocket.
- The product is intended for children 6 months and older.
- During unpacking and assembly, make sure all parts and plastic storage bags are accounted for and kept away from children. All fasteners should be fully tightened.
- Ensure all locking mechanisms are correctly engaged before use.
- Keep your children away from the product when folding and unfolding to avoid injuries.
- There are pinch points between the product supports and frame that may injure fingers. Stay clear of pinch points when opening or closing the product or when making adjustments.
- Avoid serious injury from falling or sliding out. Always use 5-point harness to secure children.
- Never leave children unattended.
- Always apply brake when taking children in or out.
- Brake must always be engaged when the product is idle to avoid injuries and accidents.
- Do not allow children to play unsupervised next to the product.
- Do not let your children play with the product.
- This product must not be operated by children under the age of 12.
- This product is not a jogger. The product is not suitable for running or skating or any similar activities.
- Never leave children in the product while ascending or descending stairs.
- Always use caution on uneven surfaces. Contents may become unstable and children could be injured by them.

- Do not hang items on the product and place anything on top of the canopy at any time. The product may become unstable.
- Do not make any alterations or modifications to the product.
- Do not use accessories, hardware, or parts that are not approved or supplied by WonderFold.
- Regularly check hardware and parts. Do not use the product if any hardware or parts are damaged or broken.
- Only use replacement parts supplied and recommended by the manufacturer.
- Any violations will void your warranty and may cause instability or structural damage to the product or personal injuries.
- NEVER press down on the handlebar while going over a curb with the stroller wagon. Lift it using the frame, not the handlebar.

Warnings in this manual can not cover all instances and unforeseen situations that may occur.

It must be understood that common sense, general caution and care are factors that can not be incorporated into a user manual.

It is important that everyone who uses the wagon understands the warnings.

Specifications

	X2R	X4R
Seat Capacity	2	4
Wagon Weight with Seats	35 lbs. (15.9 kg)	41 lbs. (18.6 kg)
Weight Capacity	150 lbs. (68 kg)	180 lbs. (81.6 kg)
Certification	ASTM F833-21, EN 1888-2:2018+A1:2022	
Age Group	6 months or above	



XR Series

Features	04
Parts Check List	05

Assembly

Unfolding the Stroller Wagon	06
Installing the Front Wheels / Installing the Rear Wheels & Brake Set	07

How to...

Secure & Release the Harness / Attach the Canopy	08
Use the Parking Brake / Recline the Seat / Adjust the Handlebar Height	09
Use the Pull Handle / Use the Footwell / Store the Canopy	10
Fold the Stroller Wagon / Use the Dust Cover	11

Maintenance & Warranty	12
------------------------------	----




X2R



X4R

Scan the QR code for a
step-by-step video

Features



5-Point Safety Harnesses


Removable Canopy

Adjustable Faux Leather Handlebar


Telescopic Pull Handle with Spring Bounce

Easy One-Step Foot Brake

All-Terrain PU Tires with Bearings & Suspensions



Footwell for Extra Leg Room




Easy to Fold & Unfold




Parts Check List

XR Series




× 1

Stroller Body




× 2

Front Wheels




× 2

Rear Wheels




× 1

Canopy




× 1

Dust Cover



X2R



X4R


Brake Set

Please make sure that all parts are included. If any parts are missing or broken, or if you need assistance assembling your stroller wagon, please contact us at hello@wonderfold.com




Assembly


Unfolding the Stroller Wagon



1. Unhook both side latches.



2. Standing on either side of the stroller, push outward and down on the center of the wagon to unfold.




3. Pull the side cover over the folding joint.






Installing / Removing the Front Wheels

Installing:





Removing:





Installing / Removing the Rear Wheels & Brake Set




Installing:



Removing:




Securing and Releasing the Harness




1. Slide the waist clip into the shoulder clip.
2. Snap the buckles together until they click in place.
3. Adjust each strap until it fits snugly.
4. Press the buckle button to release.

Attach the Canopy



1. Press the center down, then flip the canopy over.
2. Insert the canopy into the four wagon poles.






How to ...

XR Series


Use the Parking Brake

Installing:



Apply the Brake



Removing:



Release the Brake



Recline the Seat

Squeeze both tabs together and adjust the seat to the desired position.




Adjust the Handlebar Height

Press and hold the side button, then adjust to the preferred height.






Use the Pull Handle

1. Pull handle out to release from clip.
2. Pull handle up to fully extend.
3. Check that the locking mechanism is engaged.



Use the Footwell


1. Unzip then remove the footwell cover.
2. Place the footwell cover in the rear pocket to store.



Store the Canopy

1. Push the middle part downward.
2. Remove the canopy from all four poles.
3. Fold the ends together.

4. Store the folded canopy to the back of the wagon using the attached straps.







XR Series



Fold the Stroller Wagon

1. Pull up the baseboard tab.
2. Push both sides to collapse the frame.
3. Lock to secure the wagon.



Use the Dust Cover

1. Place the cover over the folded stroller wagon.
2. Snap the buckles together to keep the cover in place.



Maintenance

Cleaning the Stroller Wagon

1. Wash the stroller wagon frame with mild soap and warm water solution.
2. Rinse and wipe with a dry cloth.

Cleaning the Seat Pad

1. Spot clean with mild soap and warm water solution.
2. Rinse and wipe with a dry cloth until fully dry.

Storing the Stroller Wagon

1. Should be stored in a cool and dry place.
2. Do not store near a heat source.
3. Do not expose or store in direct sunlight or rain for a long time.

Warranty

One Year Limited Warranty

WonderFold warrants this product to be free from defects in material or workmanship for a period of one year from the date of purchase when used by the original owner according to the manufacturer's instructions.

The warranty does not apply to damage caused by product alteration, or customer/user misuse or abuse of the product. Your sales receipt is your only record of the date of purchase. Warranty is subject to change at any time at manufacturer's sole discretion. Please refer to wonderfold.com/pages/warranty for the most current version of the manufacturer warranty. Please contact WonderFold if you have any warranty questions or if you need replacement parts.

WONDERFOLD®

5796 Martin Rd

Irwindale, CA 91706

hello@wonderfold.com

1 (888) 681-1526