


CARGO CARRIER HATCH CLEARANCE

To ensure that your cargo carrier does not interfere with your hatch, please use the clearance table below.



Measured from the center of the forward bar to the open hatch at the level the top of the bars

PRODUCT NAME	MIN. CLEARANCE MEASUREMENT
<i>WB700 Aero Compact Cargo Carrier</i>	47"
<i>WB701 Aero Mid-Size Cargo Carrier</i>	51"
<i>RocketBox Pro 11 & 14</i>	45"
<i>RocketBox Pro 12</i>	40"
<i>SkyBox / Skybox Pro 16</i>	52"
<i>SkyBox / Skybox Pro 12, 18, 21 & LoPro</i>	57"