AMCREST

Amcrest-31R Earbuds User Manual



Before You Begin...

Safety Precautions

1. Do not use earbuds while driving or operating heavy machinery.
2. To avoid choking or other serious injury, keep away from small children or pets.
3. To avoid damage to the device, do not use this device in conditions below 14°F or above 104°F.
4. The earbuds come with a weatherproof rating of IPX4 which protects against rain and sweat.
5. To avoid injury to hearing, do not use this device at max volume for extended periods of time.

What's Included?

- Pair of Amcrest Bluetooth Earbuds
- Charging Case
- MicroUSB Charging Cable
- Pair of Large Silicone Eartips
- Pair of Small Silicone Eartips
- User Manual

Basic Use and Setup

Charging the Case

To charge the device, connect the included MicroUSB charging cable into the MicroUSB port located on the back of the charging case. Then, connect the USB cable into a USB port on a computer, USB charging device or 5V USB power adapter.

There are 4 LED indicators on the case which indicate battery life.

Battery Life LED Indicators

" •••• " 100%
" ••• " 75%
" •• " 50%
" • " 25%



Note: The charging case holds about 10 hours of battery power and takes about 2 hours to charge.

Initial Setup/Pairing



Once the earbuds have been fully charged remove them from the charging case. The earbuds will turn on automatically when removed.



Place the left earbud in your left ear and the right earbud in your right ear. Once pairing the earbuds will audibly prompt you that they have been properly connected.

When the earbuds have finished pairing, go to your mobile device or smartphone and access the Bluetooth connection list for your device.

Select "Amcrest-31R" from the connection list. This will be the Bluetooth name for the earbuds, and allow the device to connect. When properly connected, both earbuds will flash a blue light indicating a proper Bluetooth connection.

Using the Earbuds

Basic Operation

The earbuds turn on automatically after being fully charged and removed from the charging case. Once they have been removed a blue light on each earbud will flash for about 1 second. When attempting a connection, the left earbud will have a blue light that will flash 3 times.

Note: It is recommended to fully charge the earbuds before use. The earbuds will not turn on automatically if they are not fully charged and will have to be manually turned on.

To manually turn the earbuds on, press and hold the main button on both the left and right earbud at the same time for about 3 seconds. A blue light will show on both earbuds followed by a prompt through the earbud indicating they have been successfully turned on.

To turn the device off, place the earbuds back into the charging case and close the lid. Once they are placed back into the charging case they will automatically turn off and begin to charge. A red light will show indicating the earbuds are being charged.

Basic Use

Playing Music: To play or pause music you can press either the left or right main button during operation. To change to the next song double tap the main button on the left earbud. To return to a previous song, double tap the main button on the right earbud.

Answering a Call: To answer an incoming call press the main button on either the left or right earbud. To end the call, press the main button on either the left or right earbud. If a call comes in that you want to reject, double tap the main button on either the left or right earbud. If you are dialing a number and wish to cancel the call, press either the left or right earbud to cancel the call.

Siri/Google Assistant: If your mobile device is compatible with Siri or Google Assistant and would like to access these features using the earbuds, press and hold the main button on either the left or right earbud for about 2 seconds. A prompt will sound indicating that the Siri or Google Assistant has been activated.

Factory Reset

A factory reset of the earbuds will restore the device back to its original factory settings. After a factory reset, the earbuds will need to be reconnected to your mobile device since it has been restored to factory settings.

To restore the earbuds back to its original factory settings, press and hold the main button on the left and right earbud at the same time for 3 seconds to turn off the device. Once the earbuds have been turned off, press and hold the main buttons on the left and right earbud again for 10 seconds. An alternating red and blue light will appear on each earbud indicating a reset is taking place. Release the main buttons and allow the earbuds to reset. The flashing lights will disappear once the reset is complete.

Note: A factory reset should only be performed if the earbuds cannot connect to each other or any other connection issue is present during setup or basic use.

Charging the Earbuds

When the earbud's power reaches below 20% a red light will flash followed by a "Low Battery" prompt through the earbuds. Once the earbuds reach below 20% it is recommended to return them to the charging case, close the lid, and allow them to be properly charged. If the earbuds run completely out of battery they will automatically turn off.

Once the earbuds have been returned to the charging case a red light will begin to flash indicating the earbuds are charging. When the earbuds are fully charged the red light will disappear and the device will be ready for use. After being fully charged, the earbuds will automatically connect to your mobile device via Bluetooth once removed from the charging case.

Technical Specifications

Bluetooth Version	v5.0
Bluetooth Distance	45ft (14M)
Earbuds Play Time	50mAh*2 , up to 5 hours of charge.
Earbuds Standby Time	50 hours
Charging Case Play Time	400mAh, up to 15 extra hours
Charging Case Standby Time	150 hours
Weather Proof Rating	IPX4

Contact Us

To contact Amcrest support, please do one of the following:

Visit http://amcrest.com/contacts and use the email form
Call Amcrest Support using one of the following numbers:
Toll Free US: (888) 212-7538
International Callers (Outside of US): +1-713-893-8956
USA: 713-893-8956
Canada: 437-888-0177
UK: 203-769-2757
Email Amcrest Customer Support: https://amcrest.com/amcrestsupport

AMCREST