
Contents

Installing the Microphone.....2
Computer Setup (Windows & Mac OS).....4
Recording Software Settings.....11
Important Notice.....13

What's in the Box?



Shock Mount | Microphone | C-clamp | 3/8 to 5/8 Adapter



Windscreen Cap | 8.25ft USB Cable | Pop Filter | Desktop Boom Arm


Contact Us

Email: https://amcrest.com/othersupport

Address: 16727 Park Row Dr
Houston, TX. 77084

Call Us: Toll Free : 888.212.7538
International : +1-713-893-8956
USA : 713-893-8956
Canada : +1-437-888-0177
UK : +44-203-769-2757
Spain I Espana : +34 (902) 042513

Installing the Desktop Boom Arm




1. Slide the C-clamp onto the mounting surface and turn the lower portion of the clamp
2. Insert the desktop boom arm into the clamp.
3. Turn the knob on the clamp clockwise to secure the boom arm.
4. Fix the shock mount onto the boom arm and turn it clockwise to secure it to the arm.

When mounting the C-clamp, be sure to slide it over the side of the table making sure that both the top of the C-clamp and the underside are resting on a flat surface. Do not mount the C-clamp on overly rounded or overhanging edges.




Installing the Microphone


1. Press in on the shock mount to open the clasp. While holding the clasp open, insert the microphone into the shock mount.



2. Connect the USB cable to the microphone and plug it into a USB port on your computer.



Note: When using the microphone speak directly into the microphone diaphragm (the side of the microphone with the logo on it).



Specifications


Power Supply	USB (5V)
Polar Pattern	Uni-directional
Frequency Response	20Hz - 20KHz
Sensitivity	-43dB±3dB (at 1KHz)
Max SPL	110dB (at 1KHz≤1% T.H.D)
S/N Ratio	78dB
Electrical Current	25mA±5mA
USB Cable Length	8.25ft

Computer Setup

Apple Mac OS

1. Plug the provided USB cable into the microphone, plug the other end into a USB port on your computer. The computer will automatically recognize the device and install the driver.

2. To select the device as your audio input, open **System Preferences**.




3. Click **Sound** to display the sound preference pane.



4. Click the Input tab to verify that the microphone is selected as the default input device. Use the Input volume slider to adjust the volume if needed.



5. To adjust the output volume of the device, click on the Output tab, and ensure the "Internal Speakers" option is selected. Use the Output Volume slider to adjust the volume if needed.



Notice:
If you want to record you must open a recording software of your choice first, such as Audacity, and make sure to click "Software Playthrough(on)". This will ensure that sound is coming through correctly from the microphone.

Choose the default "Dictation & Speech" software if using speech to text. Click "On" under the Dictation window to allow the microphone to be recognized by the software.



If your computer only has a USB-C power, you will need an Apple USB-C to USB female adapter to connect the microphone to the computer. Be sure to plug the USB adapter into your computer first before connecting the microphone.




Windows


Plug the provided USB cable into the microphone, plug the other end into a USB port on your computer. The computer will automatically recognize the device and install the driver.

Please wait a few seconds and allow the driver to install. Please note, there may not be a pop-up window or message displayed while the driver is installing. After the driver has installed, you can test the microphone by speaking into it. If there is no sound, please follow the procedures below.


1. Right-click on the speaker icon at the bottom right of the screen and click "**Open Sound Settings.**"




2. Choose **Sound Control Panel**.




3. Confirm the speaker option is enabled.




To adjust the speaker volume, click on **Properties** and click on the **Levels** tab. Use the volume slider to adjust the speaker volume output levels.




4. Exit the speaker tab and select the Recording tab. Select the USB microphone as the default option and speak into the microphone. If the levels are not registering, please restart your computer and plug the device back into the USB port.



If you would like to listen to the output level, click on **Properties** and select the **Listen** tab. Click on **Listen to this Device** then click **Apply**. The audio from the microphone will be heard in the external speakers or, if headphones are connected, through the headphones.
Note: If you are using a chat software, such as Skype, please make sure **"Listen to Device"** is disabled.



5. To adjust the microphone levels, click on the Levels tab, right-click on the speaker icon, and select decibels. For optimal use, have the decibel ranges between +14.0 to +20.0dB. Click the OK button.



Troubleshooting & Tips


1. If the computer is unable to identify the USB microphone, please restart the computer and replug the microphone back into the USB port.

2. If the microphone is recognized but no sound is coming out, please check if the computer's sound is muted or if the volume for the microphone is too low.

3. If the microphone is running on Windows 10 and is not being recognized, please go to **settings>privacy>microphone** and click the **Allow apps** option to turn the microphone to **ON** and then restart the computer.

Recording Software Settings

1. In this section, we will be using Audacity and Skype however the same concept can be used with your favorite recording software. Please make sure the correct input/output options are selected in the software.




Input: USB Microphone



Output: Choose your output device if needed


2. If the microphone is echoing, please make sure to disable **"Listen to this device"** in the microphone properities menu when using recording software.



3. Click the record button to begin recording audio.



If using Skype, please use the following image as a reference for adjusting your microphone settings.



Important Notice

• Setting software levels
Correcting microphone levels are a crucial step in optimizing performance. Ideally, the microphone level should be as high as possible without overloading the input of your computer. If you hear distortion, or if the recording software shows levels that are consistently at peak levels, turn the microphone volume down either through the control panel on your computer or through the recording software. If the recording software shows insufficient levels, you can increase the gain through the control panel or using the recording software.

• Selecting Software
The microphone is compatible with your favorite recording software as long as your computer supports a USB connection. Many programs, such as Audacity, are widely used and available free for download.
Note: The driver for the microphone must be installed first before accessing recording software.

• Positioning the Microphone
Position the microphone directly in line with the sound source and speak directly into the microphone diaphragm (the side with the logo on it) to achieve the best sound quality.

• Protecting the Microphone
Avoid leaving the microphone in the open air or in areas where temperatures exceed 110°F (43°C) for extended lengths of time or where high humidity is present.

AMCREST

CARDIOID MICROPHONE KIT

WITH POP-FILTER, SHOCK MOUNT
& ADJUSTABLE HEAVY METAL BOOM STAND

USER MANUAL

MODEL: **AM430-BPS**

