AMCREST
SmartHome

Quick Setup Guide

4MP Wi-Fi Bullet Outdoor Security Camera

Model: **ASH42**





How can we help?

We are dedicated to providing the highest quality support to our customers and are available 7 days a week.

Online Video Turorial & Quick Start Guide
amcrest.com/support

Need help?
support@amcrest.com
1-888-212-7538

01
Setting Up the Camera

The Amcrest Smart Home app connects your Amcrest camera to your Android or iOS mobile device, ensuring you are always connected to what matters most.

Download on the App Store

GET IT ON Google Play

To get the app, search for **"Amcrest Smart Home"** in the Google Play or App Store

Note: In order to add your device on the **Amcrest View Pro** app you must complete setup on the **Amcrest Smart Home** app first. Then follow the link below.
amcrest.com/usingviewpro

Connecting to the SmartHome app

Important: Please complete the entire initial setup in close proximity to your WiFi router to ensure a stable connection.

Ensure your device is powered using the included power supply and open the Amcrest Smart Home app.

Tap on **"Register"** to register an account. After registering an account, log into the app and tap **"Add Device"**.

You will need to allow all notification and location permissions to allow the camera to connect to your mobile device.



Scan the QR Code or Manually Enter the S/N

Scan the QR code located on the bottom of your camera.

If you are unable to scan the QR code you can manually enter the serial number by tapping **"Manually enter SN"**.



Choose Your Setup Method

Choose between Wi-Fi and Ethernet Only Setup. Please note, the camera can **only** function on either a Wi-Fi or Ethernet connection, the camera cannot connect to both.

Follow the in app instructions to complete setup.

Wi-Fi (Recommended)

This method allows you to connect the device to your network via Wi-Fi using the camera's built-in Wi-Fi hotspot.

Ethernet Only

This method uses an Ethernet only connection to connect to your device to the network.

Note: Your camera must be on the same network as your mobile device during either setup method.



02
Camera Features

Devices
Displays added devices in the app.

Events
Provides quick access to motion events and alerts.

Account
Manage account settings and information.

The main screen on the Amcrest Smart Home app will be your Devices menu. This menu displays all of your added devices.



Built-in Microphone

Use the built-in microphone feature to listen to what matters most, anytime, anywhere.



SmartHome Cloud Storage

Use the Amcrest Smart Home premium cloud service to view, record and playback events from a secure, off-site location.



MicroSD Card Storage

A MicroSD card can also be used to record and playback events locally.

Note:
The MicroSD card must be class 10 or higher and formatted to FAT32.



Motion Detection

Motion Detection allows you to receive alerts and automatically record footage anytime your camera detects motion.



Smart Notifications

Receive email and push notifications directly to your smartphone using the Amcrest Smart Home app.

Note:
To learn more about Smart Notifications visit:
amcrest.com/smartnotifications

