

Voyager

QUICK START GUIDE




Garage Door Opener
Instrument Cluster Display Buttons
Cruise Control Buttons
Radio On/Off & Volume
Gear Selector
Electric Park Brake
Storage Drawer Access Button
Tune/Browse Button
AUX/Media USB Ports (C/A)
Power Outlet/USB Charge-Only Ports (C/A)

Garage Door Opener



1 While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2 Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:

Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.

ROLLING OR NON-ROLLING?

Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

3 **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4 For Rolling Code garage door openers only, firmly push and release the "LEARN" or "TRAIN" button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).

5 If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

Scan For HomeLink® Video

NEED ASSISTANCE?
1-800-355-3515

LINK YOUR GARAGE DOOR

Pair a Phone



1. Make sure Bluetooth® is enabled on your mobile device
2. With the vehicle in the ON/RUN or ACC position, press the Phone button on the vehicle's touchscreen menu bar
3. Press "Device Manager"
4. Select "Add Device"
5. Follow the prompts on your phone and on the touchscreen

CONNECT YOUR APPS

Connect your smartphone to the media USB port or pair your smartphone within Device Manager. The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.

KEEP IN MIND:

For Android™ Users, if the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.

For Apple® Users, Apple CarPlay® is only compatible with iPhone® 5 or later and requires Siri being enabled in "Settings".

Ready to remove a phone or audio device?

1. Press "Device Manager" on the touchscreen.
2. Press the "Settings" gear icon next to the phone or device you wish to remove.
3. Press "Delete Device". The device should be removed.



Connected Services

WITH CONNECTED SERVICES YOU CAN...

- **Lock Your Vehicle**
- **Unlock Your Vehicle**
- **Remote Start Your Vehicle**
- **Cancel Remote Start**
- **Activate Your Horn**

ACTIVATE YOUR REMOTE SERVICES

GO

1. Press “Apps” on the touchscreen.
2. Press “Activate Services”.
3. Press “Activate Now”.
4. There are two ways to activate: via email or via an agent. On the next screen, you can either enter your name and email, or press “Call An Agent” to directly speak with an agent.

Mopar® YOUR Way

CREATE YOUR OWNER’S PROFILE TODAY!

Get 24/7 Access To Everything You Need

- Custom vehicle dashboard
- Access to your vehicle’s Owner’s Information
- Schedule dealer service with ease
- Obtain special offers on Mopar® service
- View maintenance records**
- Mobile vehicle commands**

**Requires an active SiriusXM Guardian™ subscription

Registration is simple. Scan the QR code below and provide your email address to get started.

Scan me
(U.S. Residents Only)*

*Canadian residents are not required to create a profile, as one is created when a SiriusXM Guardian™ account is activated.

GET PERSONALIZED BY REGISTERING

Head Restraints

FRONT SEATS FOUR-WAY HEAD RESTRAINTS


FORWARD ADJUSTMENT

To **tilt forward**, pull the top of the head restraint toward the front of the vehicle to the desired position.

REARWARD ADJUSTMENT

To **tilt rearward**, pull the top of the head restraint to the furthest forward position and the head restraint will return to the upright position.

TILTED



UPRIGHT



UP/DOWN ADJUSTMENT

Pull up on the head restraint to raise it.

Push the adjustment button while pushing down on the head restraint to lower it.

REMOVAL

With the head restraint raised all the way, push the release and adjustment buttons while pulling up on the head restraint.

INSTALLATION

Insert the head restraint posts into the holes and push downward.



ADJUSTMENT BUTTON

RELEASE BUTTON

TIP:

The seatback angle may need to be adjusted to fully remove the head restraint.

Scan For Head Restraint Video

Stow 'n Go Seating

STOW YOUR SECOND ROW SEATS FOR EXTRA CARGO SPACE

1. Place the **LOCK KNOB** in the unlocked position.
2. Pull the **FLOOR LATCH** and push the panel forward.
3. Pull the **STRAP** and guide the seat into the storage area.



FLOOR LATCH



PULL STRAP

PUSH TO LOCK



STOWED SEATS



4. Push down on the **SEAT** to lock it into the storage area.
5. Close the **FLOOR PANEL** and push down to lock it into place.

Scan For Stow 'n Go Video

Uconnect 5/5 NAV

HOME: Customize your Home page with Widgets.

MEDIA: Listen to radio stations and play media.

COMFORT: Adjust the vehicle's multiple climate control options.

PHONE: Pair your smartphone and make hands-free calls.

VEHICLE: Access vehicle settings and vehicle specific features.

APPS: Access any app installed on your Uconnect system.

INSTRUMENT CLUSTER SCREEN SETUP

Customize displayed information such as the time:

1. Use the Up and Down arrows to select "Screen Setup" in the instrument cluster display.
2. Select an area of the cluster to display the time. Once selected, pick "Time". The current time will now display in that area of the cluster.



Scan For Radio Video

Warning & Indicator Lights

	Air Bag		Battery Charge		Brake		Door Open		Electric Power Steering Fault
	Electronic Throttle Control (ETC)		Engine Coolant Temperature		Hood Open		Liftgate Open		Oil Pressure
	Oil Temperature		Seat Belt Reminder		Transmission Temperature		Vehicle Security		Anti-Lock Brake System (ABS)
	Electric Park Brake (EPB)		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF		Engine Check/ Malfunction Indicator		Forward Collision Warning (FCW) Off
	Low Fuel		Low Washer Fluid		Service Forward Collision Warning (FCW)		Service Stop/Start System		Tire Pressure Monitoring System (TPMS)
	Cruise Control Set		Front Fog		KeySense		Parking Lights/ Headlights On		Stop/Start Active
	Turn Signal		Cruise Control Ready		Set Speed Display		High Beam		

For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2022 FCA US LLC. All Rights Reserved. Tous droits réservés. Chrysler is a registered trademark of FCA US LLC or FCA Canada Inc., used under license.
Chrysler est une marque déposée de FCA US LLC ou FCA Canada Inc., utilisée sous le permis. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

Second Edition
RUV_QSG_EN_US_BA