BATTERY USE & CHARGING

This Dash Cordless Collection appliance is powered by a Rechargeable Lithium-Ion Battery designed for quick charging and long-lasting performance.

BEFORE FIRST USE

- For best performance, fully charge the Battery before using the appliance.
- Place the Charging Stand on a flat, stable surface.

TO CHARGE

1. Insert the Battery into the Charging Stand. It will click into place when properly seated.
2. Plug the Charging Stand into a wall outlet.
3. The Indicator Light will glow red while charging. When fully charged, the Light will turn white.
4. A full charge takes approximately 2½ hours.

USE AND CARE

- Charge only indoors on a dry, level surface.
- Avoid using or storing the Stand near water, heat, or direct sunlight.
- Only charge at room temperature. Avoid charging in damp or wet conditions.
- The Lithium-Ion Battery can only be charged using the Dash Cordless Collection Charging Stand.
- Do not leave the Battery in the Charging Stand once fully charged.
- Always unplug the Charging Stand when not in use or before cleaning.