www.drivetech.info

drive DeVilbiss HEALTHCARE

Joystick Locking & Unlocking

www.drivetech.info

drive DeVilbiss HEALTHCARE

VR2 CONTROLLER



INDICATION



Profile LEDs scroll left to right.

TO UNLOCK:

Hold Joystick forward until beep, then pull Joystick back until beep. There will be a long beep indicating unit is unlocked.

TO LOCK:

While powered on, hold On/Off Key until beep, then release. Push Joystick forward until beep, then pull Joystick back until beep. Unit is now locked.

VSI CONTROLLER



INDICATION



Profile LEDs scroll left to right.

TO UNLOCK:

Push joystick forward until beep then pull joystick back until beep. Unit is now unlocked.

TO LOCK:

Hold On/Off Key until beep, then release. Push Joystick forward until beep, then pull Joystick back until beep. There will be a long beep indicating unit is locked.

DYNAMIC CONTROLLER



INDICATION



Battery Indicator LEDs scroll right to left.

TO UNLOCK:

Press the Horn Key twice during the 10 seconds (approximately) that the indicator LEDs are scrolling. The controller is now unlocked.

TO LOCK:

While the power is on, press and hold the On/Off Key for 4 seconds. The display will turn off immediately. After 4 seconds, all LEDs will flash briefly and the horn will sound a short beep.

LINX CONTROLLER



INDICATION



Flashing LEDS 1, 3 & 5

TO UNLOCK:

Press the power button once. Then press the horn button twice within 10 seconds.

TO LOCK:

Press and hold the power button for 4 seconds.