Quick Tips

Frames: [Settings] + [Enter] Vertical: [Settings] + [◄][►] + [Enter]

Save/retrieve label: [Shift] + [▲][▼]

Beginning/end of line: [Shift] + [◄][►]

Next line/enter: [Enter]

Font: [AA] Font size: [A] Font style: [AA]

Symbols: [★] Punctuation: [.,?!] or [Shift] + [.,?!]

Caps Lock: [aA]

Delete character: [⌫] Delete label: [Shift] + [⌫]

Settings: [Settings] Display settings: [Shift] + [Q]

CPD-34897 155316900