Fanttik

S1 NEX Studio

User Manual



Please read this instruction manual carefully before use and keep it for future reference.

Contents

1.Attention ---- 02
2.Product Overview ---- 03
3.How to Use ---- 04
4.Specifications ---- 07
5.Warranty Info ---- 08

1.Attention

- Avoid moisture, dust, and drop.
- Do not store the product in extreme temperature environment
- Stay alert, watch what you are doing and use common sense when operating. Do not operate while you are tired or under the influence of drugs, alcohol or medication.
- This product is not a toy and should not be used by kids under 5 years old.
- This product has built-in battery, do not throw it into fire and should be recycled by local laws and regulations.
- Do not dismantle the machine by yourself, Have your power tool serviced by a qualified repair person or contact us for advice.

2.Product Overview

1-Cordless Screwdriver

2-Screwdriver Bit Set

3-Extension Bit Holder

4-TYPE-C Cable

5-Hammer（with Rubber Cap）

6-Adjustable Wrench

7-Combination Pliers

8-Tape Measure

9-Hex Wrench Set

10-Utility Knife



3.How to Use



Open the toolbox

●Press the middle part of the handle and pull out the inner box after hearing a click.

Close the toolbox

●Insert the inner box into the outer box and press the middle of the handle until you hear a click.

Screwdriver power on&off

- Turn the torque knob from OFF to any desired level, then press the forward/reverse rotation button to start the screwdriver.
- Turn the torque knob to OFF to turn off the screwdriver.

Turn on/off the LED light

- The LED light turns on simultaneously when the screwdriver is turned on.
- The LED light will stay on for 10 seconds without any operation.
- The LED light will turn off when the torque knob is turned to OFF.

Forward/Reverse rotation button

- Press the Forward ∧ / Reverse ∨ rotation button to tighten or loosen a screw.

Torque knob

- Turn the knob to level I to set to low torque mode.



- Turn the knob to level II to set to medium torque mode.
- Turn the knob to level III to set to high torque mode.

Power Indicator

- When the battery level is below 20% in use, the indicator will rapidly blink red, and it will turn off in 5 seconds after the rotation button is released.
- When charging, the indicator will slowly blink white.
- When the battery is fully charger, the indicator will become solid white.

Battery charging

- This screwdriver is equipped with a universal Type-c charging port, and comes with a USB charging cable. Charger is not included, please use a 5V charger for charging

4.Specifications

Product Name	Cordless screwdriver kit
Product Model	S1 NEX Studio
Screwdriver dimension	184x Φ35 mm
Max. hard torque	6N·m
Max. manual torque	8N·m
Kit Net Weight	3.3KG
Charging Input	5V ⎓ 1A
Rated Voltage	3.7V
Lithium Battery	2000mAh
Rotation speed (unloaded)	220rpm
Charging time	2-3H
Screwdriver Bit Parameters	
Bit Shank	1/4-Inch (6.3mm)
Bit Length	1-Inch (25mm)
Bit Material	Coated S2 Steal
Bit list	PH0/PH1/PH2/S2/H4/H5/SL3/SL4/SL5/TR25

5.Warranty Info

WARRANTY

- This product is covered by a **12-month** warranty for manufacturing defects.

929-693-6066 MON-FRI 9AM-5PM[ET]
www.fanttik.com
support@fanttik.com
Manufacturer/Hersteller: METASEE LLC
Address/Adresse: 12 GREENWAY PLZ STE 1161A
HOUSTON, TX 77046-1203

Made in China

